



LoRaWAN 4-Detect-Channels Distance Sensor User Manual

Document Version: 1.1

Image Version: v1.0

Version	Description	Date
1.0	Release	2021-Aug-19

1.	Introduction	4
1.1	What is LoRaWAN 4-Channels Distance Sensor	4
1.2	Features	5
1.3	Applications	5
1.4	Pin mapping and power on	5
1.5	Probe Options	6
1.5.1	Probes Comparation	6
1.5.2	A01A-15 probe	7
1.5.3	A02-15 probe	9
1.5.4	A13-15 probe	10
1.5.5	A16-15 probe	12
2.	Configure LDDS04 to connect to LoRaWAN network	14
2.1	How it works	14
2.2	Connect Probe	14
2.3	Quick guide to connect to LoRaWAN server (OTAA)	15
2.4	Uplink Payload	19
2.4.1	Battery Info	19
2.4.2	Interrupt Pin	19
2.4.3	Distance	19
2.4.4	Message Type	20
2.4.5	Decode payload in The Things Network	21
2.5	Uplink Interval	21
2.6	Show Data in DataCake IoT Server	22
2.7	Frequency Plans	28
2.7.1	EU863-870 (EU868)	28
2.7.2	US902-928(US915)	28
2.7.3	CN470-510 (CN470)	28
2.7.4	AU915-928(AU915)	29
2.7.5	AS920-923 & AS923-925 (AS923)	29
2.7.6	KR920-923 (KR920)	29
2.7.7	IN865-867 (IN865)	30
2.8	LED Indicator	30
2.9	Firmware Change Log	30
3.	Configure LDDS04 via AT Command or LoRaWAN Downlink	31
3.1	Set Transmit Interval Time	31
3.2	Set Interrupt Mode	32
3.3	Get Firmware Version Info	32
4.	Battery & how to replace	33
4.1	Battery Type	33
4.2	Replace Battery	34
4.3	Power Consumption Analyze	34
4.3.1	Battery Note	35
4.3.2	Replace the battery	35
5.	Use AT Command	36
5.1	Access AT Commands	36
6.	FAQ	37

6.1	How to change the LoRa Frequency Bands/Region	37
7.	Trouble Shooting	37
7.1	AT Commands input doesn't work	37
8.	Order Info	37
8.1	Main Device LDDS04	37
8.2	Probe Model	37
9.	Packing Info	38
10.	Support	38

1. Introduction

1.1 What is LoRaWAN 4-Channels Distance Sensor

The Dragino LDDS04 is a **LoRaWAN 4-Channels Distance Sensor** for Internet of Things solution. It is capable to add up to four Ultrasonic Sensors to measure four distances at the same time.

The LDDS04 can be applied to scenarios such as horizontal distance measurement, parking management system, object proximity and presence detection, intelligent trash can management system, robot obstacle avoidance, automatic control, sewer, etc.


It detects the distance between the measured object and the sensor, and uploads the value via wireless to LoRaWAN IoT Server.

The LoRa wireless technology used in LDDS04 allows device to send data and reach extremely long ranges at low data-rates. It provides ultra-long range spread spectrum communication and high interference immunity whilst minimizing current consumption.

LDDS04 is powered by **8500mAh Li-SOCI2 battery**, it is designed for long term use up to 5 years.

Each LDDS04 is pre-load with a set of unique keys for LoRaWAN registrations, register these keys to local LoRaWAN server and it will auto connect after power on.

LDDS04 in a LoRaWAN IoT Network




1.2 Features

- ◇ LoRaWAN 1.0.3 Class A
- ◇ Ultra-low power consumption
- ◇ Detect Range: Base on External Probe
- ◇ Monitor Battery Level
- ◇ Bands: CN470/EU433/KR920/US915/EU868/AS923/AU915/IN865
- ◇ AT Commands to change parameters
- ◇ Uplink on periodically
- ◇ Downlink to change configure
- ◇ 850mAh Battery for long term use

1.3 Applications





- ◇ Horizontal distance measurement
- ◇ Parking management system
- ◇ Object proximity and presence detection
- ◇ Intelligent trash can management system
- ◇ Robot obstacle avoidance
- ◇ Automatic control
- ◇ Sewer

1.4 Pin mapping and power on



1.5 Probe Options

1.5.1 Probes Comparison



Model	Photo	Description
A01A-15		Detect Distance: 28 cm ~ 750 cm Bling Spot Distance: 0 ~ 28cm Accuracy: $\pm(1\text{cm}+S*0.3\%)$ (S: Distance) Measure Angle: $\sim 40^\circ$ Cable Length: 1.5 meter Temperature Compensation Suitable for Flat Object Detect IP67 Water Proof
A02-15		Detect Distance: 3cm ~ 450cm Bling Spot Distance: 0 ~ 3cm Accuracy: $\pm(1\text{cm}+S*0.3\%)$ (S: Distance) Measure Angle: $\sim 60^\circ$ Cable Length: 1.5 meter Temperature Compensation Suitable for Flat Object Detect, Rubbish Bin IP67 Water Proof
A13-15		Detect Distance: 25cm ~ 200cm Bling Spot Distance: 0 ~ 25cm Accuracy: $\pm(1\text{cm}+S*0.3\%)$ (S: Distance) Measure Angle: $\sim 20^\circ$ Cable Length: 1.5 meter Temperature Compensation Suitable for Flat Object Detect, Rubbish Bin IP67 Water Proof
A16-15		Detect Distance: 50cm ~ 1500cm Bling Spot Distance: 0 ~ 50cm Accuracy: $\pm(1\text{cm}+S*0.3\%)$ (S: Distance) Measure Angle: $\sim 40^\circ$ Cable Length: 1.5 meter Temperature Compensation Suitable for Long Distance Detect IP67 Water Proof

1.5.2 A01A-15 probe



A01A-15 is mainly used for plane distance measurement; it can carry out targeted measurement on plane objects and can measure long distances and high accuracy.

Beam Chart:


(1) The tested object is a white cylindrical tube made of PVC, with a height of 100cm and a diameter of 7.5cm.



(2) The object to be tested is a "corrugated cardboard box" perpendicular to the central axis of 0°, and the length * width is 60cm * 50cm.



Mechanical:




Application:




1.5.3 A02-15 probe

Beam Chart:


(1) The tested object is a white cylindrical tube made of PVC, with a height of 100cm and a diameter of 7.5cm.



(2) The object to be tested is a "corrugated cardboard box" perpendicular to the central axis of 0°, and the length * width is 60cm * 50cm.



Mechanical:




Application:



1.5.4 A13-15 probe


Beam Chart:

(1) The tested object is a white cylindrical tube made of PVC, with a height of 100cm and a diameter of 7.5cm.



(2) The object to be tested is a "corrugated cardboard box" perpendicular to the central axis of 0°, and the length * width is 60cm * 50cm.

Mechanical:




单位: mm

Installation Requirement:

- 1) The effective detection range of the product is 25cm-200cm, so the vertical distance between the installation position of the module and the bottom of the trash bin is required to be less than 200cm.
- 2) The installation position of the product should be perpendicular to the trash bin to maintain a good horizontal plane, and be located at the center of the trash bin diameter;
- 3) In order to effectively filter out the reflection echo from the diameter of the trash bin and baffle, the distance between the installation position of the module and the edge of the diameter of the trash bin (non-vertical horizontal distance) is required to be 30cm

For trash bins between 80cm and 25cm in diameter, it is recommended that the installation position of the module and the height of the trash bin (the vertical and horizontal distance) be 30cm. For trash bins with a diameter of about 60cm, it is recommended that the installation position of the module and the height of the trash bin (vertical horizontal distance) be between 30cm-50cm. There is no such restriction on large-diameter (>60cm) trash bins.



超声波探测器安装示意图


Application:




1.5.5 A16-15 probe

Beam Chart:


(1) The tested object is a white cylindrical tube made of PVC, with a height of 100cm and a diameter of 7.5cm.



(2) The object to be tested is a "corrugated cardboard box" perpendicular to the central axis of 0°, and the length * width is 60cm * 50cm.



Mechanical:



Unmarked dimension tolerances as below.

TOLERANCE (mm)	0~10	≥10~30	≥30~50	≥50~100	≥100~200
	±0.1	±0.15	±0.2	±0.3	±0.5

Application:



2. Configure LDDS04 to connect to LoRaWAN network

2.1 How it works


The LDDS04 is configured as LoRaWAN OTAA Class A mode by default. It has OTAA keys to join LoRaWAN network. To connect a local LoRaWAN network, you need to input the OTAA keys in the LoRaWAN IoT server and power on the LDDS04. It will automatically join the network via OTAA and start to send the sensor value. The default uplink interval is 20 minutes.

2.2 Connect Probe

LDDS04 has a converter, User need to connect the Ultrasonic Probes to the convert as below. Different probes are supported, please see this link for the probe options.




Probe mapping as below.



2.3 Quick guide to connect to LoRaWAN server (OTAA)

Following is an example for how to join the [TTN v3 LoRaWAN Network](#). Below is the network structure; we use the DLOS8 as a LoRaWAN gateway in this example.

LDDS04 in a LoRaWAN IoT Network



The LG308 is already set to connected to [TTN network](#), so what we need to now is configure the TTN server.

Step 1: Create a device in TTN with the OTAA keys from LDDS04. Each LDDS04 is shipped with a sticker with the default device EUI as below:



You can enter this key in the LoRaWAN Server portal. Below is TTN screen shot:

Register the device

Register end device

From The LoRaWAN Device Repository [Manually](#)

Preparation

Activation mode *

- Over the air activation (OTAA)
- Activation by personalization (ABP)
- Multicast
- Do not configure activation

LoRaWAN version Ⓞ *

Network Server address

Application Server address

External Join Server Ⓞ

 Enabled

Join Server address

[Start](#) 

Add APP EUI and DEV EUI

Register end device

From The LoRaWAN Device Repository [Manually](#)

- 1 Basic settings**
End device ID's, Name and Description
- 2 Network layer settings
Frequency plan, regional parameters, end device class and session keys.
- 3 Join settings
Root keys, NetID and kek labels.

End device ID Ⓞ *

AppEUI Ⓞ

DevEUI Ⓞ *

End device name

End device description

Optional end device description; can also be used to save notes about the end device

[Network layer settings >](#)

Add APP EUI in the application

Register end device

From The LoRaWAN Device Repository [Manually](#)

- 1 **Basic settings**
 End device ID's, Name and Description
- 2 **Network layer settings**
 Frequency plan, regional parameters, end device class and session keys.
- 3 **Join settings**
 Root keys, NetID and kek labels.

Frequency plan ⓘ *
 Europe 863-870 MHz (SF12 for RX2)

LoRaWAN version ⓘ *
 MAC V1.0.3

Regional Parameters version ⓘ *
 PHY V1.0.3 REVA

LoRaWAN class capabilities ⓘ

- Supports class B
- Supports class C

Advanced settings ▾

< Basic settings
Join settings >

Add APP KEY

Register end device

From The LoRaWAN Device Repository [Manually](#)

- 1 **Basic settings**
 End device ID's, Name and Description
- 2 **Network layer settings**
 Frequency plan, regional parameters, end device class and session keys.
- 3 **Join settings**
 Root keys, NetID and kek labels.

Root keys

AppKey ⓘ *
 BD 72 1D AC F3 CC AB 67 72 8D 7A F5 4D DF 30 8B

Advanced settings ▾

< Network layer settings
Add end device

Step 2: Power on LDDS04

Put a Jumper on JP2 to power on the device. (The Switch must be in FLASH position).



Step 3: The LDDS04 will auto join to the TTN network. After join success, it will start to upload messages to TTN and you can see the messages in the panel.

ldds04
ID: ldds04

Last seen info unavailable ↑ 1 ↓ n/a Created 23 minutes ago

Overview Live data Messaging Location Payload formatters Claiming General settings


Time	Type	Data preview	Verbose stream	Pause	Clear
↑ 14:54:25	Forward uplink data message	{1_cm: 79, distance2_cm: 79.2, distance3_cm: 79.4, distance4_cm: 78.5 }	0D 41 03 16 03 18 03 1A ...	FPort: 2 Data rate: SF8BW125	
↑ 14:54:09	Forward uplink data message	{1_cm: 79, distance2_cm: 79.2, distance3_cm: 79.4, distance4_cm: 78.9 }	0D 4A 03 16 03 18 03 1A ...	FPort: 2 Data rate: SF12BW125	
⊞ 14:53:59	Accept join-request				

2.4 Uplink Payload

LDDS04 will uplink payload via LoRaWAN with below payload format:

Uplink payload includes in total 11 bytes.

Size (bytes)	2	2	2	2	2	1
Value	BAT & Interrupt flag	Distance of UT sensor1	Distance of UT sensor2	Distance of UT sensor3	Distance of UT sensor4	Message Type



ldds04
ID: ldds04

Last seen info unavailable ↑ 1 ↓ n/a Created 23 minutes ago

Overview **Live data** Messaging Location Payload formatters Claiming General settings

Time	Type	Data preview	Verbose stream	Pause	Clear
↑ 14:54:25	Forward uplink data message	1_cm: 79, distance2_cm: 79.2, distance3_cm: 79.4, distance4_cm: 78.5	80 41 03 16 03 18 03 1A ...	FPort: 2 Data rate: SF8BW125	
↑ 14:54:09	Forward uplink data message	1_cm: 79, distance2_cm: 79.2, distance3_cm: 79.4, distance4_cm: 78.9	80 4A 03 16 03 18 03 1A ...	FPort: 2 Data rate: SF12BW125	
⌵ 14:53:59	Accept join-request				

2.4.1 Battery Info

Check the battery voltage for LDDS04.

Ex1: 0x0D4A & 0x3FFF = 3402mV

Ex2: 0x8D41 & 0x3FFF = 3393mV

2.4.2 Interrupt Pin

This bit shows if uplink packet is generated by Interrupt Pin or not. [Click here](#) for the hardware and software set up. Note: The Internet Pin is a separate pin in the screw terminal. See [pin mapping](#).

Example:

(0x0D4A & 0x8000) >>15 = 0: Normal uplink packet.

(0x8D41 & 0x8000) >>15 = 1: Interrupt Uplink Packet.

2.4.3 Distance

The measuring distance of the four distance measuring modules, the default unit is cm.

Example:

Uplink Payload: 0D 4A 03 16 03 18 03 1A 03 15 01

Data analysis:

Distance of UT sensor1 : 0316(H) = 790 (D)/10 = 79cm.

Distance of UT sensor2 : 0318(H) = 792 (D)/10 = 79.2cm.

Distance of UT sensor3 : 031A(H) = 794 (D)/10 = 79.4cm.


Distance of UT sensor4 : 0315(H) = 789 (D)/10 = 78.9cm.

2.4.4 Message Type

For a normal uplink payload, the message type is always 0x01.

Valid Message Type:

Message Type Code	Description	Payload
0x01	Normal Uplink	Normal Uplink Payload
0x02	Reply configures info	Configure Info Payload



ldds04
ID: ldds04


Last seen 46 seconds ago ↑ 8 ↓ 3 Created 2 hours ago

Overview **Live data** Messaging Location Payload formatters Claiming General settings

Time	Type	Data preview
↑ 16:33:25	Forward uplink data message	distance3_cm: 79.3, distance4_cm: 78.9, mes_type: 2 } 8D 3E 03 17 03 17 03 19 ...
↑ 16:33:12	Forward uplink data message	distance3_cm: 79.3, distance4_cm: 78.9, mes_type: 1 } 8D 3E 03 16 03 17 03 19 ...
↓ 16:33:04	Forward downlink data message	FPort: 2 Payload: 01 00 01 2C
≡ 16:32:59	Console: Events cleared	The events list has been cleared

2.4.5 Decode payload in The Things Network

While using TTN network, you can add the payload format to decode the payload.



The screenshot shows the 'Payload formatters' configuration page. The 'Payload formatters' tab is selected and highlighted with a red box. Under 'Formatter type', the 'Javascript' radio button is selected and highlighted with a red box. The 'Formatter parameter' field contains the following JavaScript code:

```

1 function decodeUplink(input) {
2   return {
3     data: {
4       bytes: input.bytes
5     },
6     warnings: [],
7     errors: []
8   };
9 }

```

The payload decoder function for TTN is here:

LDDS04 TTN Payload Decoder:

https://www.dragino.com/downloads/index.php?dir=LoRa_End_Node/LDDS04/Decoder/

```

function Decoder(bytes, port) {
  var decode = {};
  var value=(bytes[0]<<8 | bytes[1]) & 0x3FFF;
  decode.BatV= value/1000;
  decode.EXTI_Trigger=(bytes[0] & 0x80)? "TRUE":"FALSE";
  decode.distance1_cm=(bytes[2]<<8 | bytes[3])/10;
  decode.distance2_cm=(bytes[4]<<8 | bytes[5])/10;
  decode.distance3_cm=(bytes[6]<<8 | bytes[7])/10;
  decode.distance4_cm=(bytes[8]<<8 | bytes[9])/10;
  decode.mes_type= bytes[10];

  if(!((bytes[0]==0x03)&&(bytes[10]==0x02)))
  {
    return decode;
  }
}

```

2.5 Uplink Interval

The LDSS04 by default uplink the sensor data every 20 minutes. User can change this interval by AT Command or LoRaWAN Downlink Command. See this link:


http://wiki.dragino.com/index.php?title=End_Device_AT_Commands_and_Downlink_Commands#Change_Uplink_Interval

2.6 Show Data in DataCake IoT Server

[DATAKAKE](#) provides a human friendly interface to show the sensor data, once we have data in TTN, we can use [DATAKAKE](#) to connect to TTN and see the data in DATAKAKE. Below are the steps:

Step 1: Be sure that your device is programmed and properly connected to the network at this time.

Step 2: To configure the Application to forward data to DATAKAKE you will need to add integration. To add the DATAKAKE integration, perform the following steps:



Add custom webhook

Template information



Datacake

Send data to Datacake via TTI adapter

[About Datacake](#) | [Documentation](#)

Template settings

Webhook ID *

Token *

Datacake API Token

Create datacake webhook

Step 3: Create an account or log in Datacake.

Step 4: Create LDDS04 product.

STEP 1
Product

STEP 2
Network Server

STEP 3
Devices

STEP 4
Plan

Datacake Product

You can add devices to an existing product on Datacake, create a new empty product or start with one of the templates. Products allow you to share the same configuration (fields, dashboard and more) between devices.

New Product from template

Create new product from a template

Existing Product

Add devices to an existing product

New Product

Create new empty product

New Product

If your device is not available as a template, you can start with an empty device. You will have to create the device definition (fields, dashboard) and provide the payload decoder in the device's configuration.

Product Name

Next

Add Device



LoRaWAN



PARTICLE



API



D Zero



D Zero LTE



PINCODE

STEP 1
Product

STEP 2
Network Server

STEP 3
Devices

STEP 4
Plan

Network Server

Please choose the LoRaWAN Network Server that your devices are connected to.

<input checked="" type="radio"/>		The Things Stack V3 TTN V3 / Things Industries	<input type="button" value="Uplinks"/>	<input type="button" value="Downlinks"/>
<input type="radio"/>		The Things Network V2 The old Things Network	<input type="button" value="Uplinks"/>	<input type="button" value="Downlinks"/>
<input type="radio"/>		Helium	<input type="button" value="Uplinks"/>	<input type="button" value="Downlinks"/>
<input type="radio"/>		LORIoT	<input type="button" value="Uplinks"/>	<input type="button" value="Downlinks"/>
<input type="radio"/>		Kerlink Wanesy	<input type="button" value="Uplinks"/>	

Showing 1 to 5 of 8 results

Add Device ✕



LoRaWAN



PARTICLE



API



D Zero



D Zero LTE



PINCODE

STEP 1
Product

STEP 2
Network Server

STEP 3
Devices

STEP 4
Plan

Add Devices

Enter one or more LoRaWAN Device EUIs and the names they will have on Datacake.

DEVEUI	NAME
49 87 44 16 16 98 74 0x 8 bytes	LDDS04
<input type="button" value="+ Add another device"/>	

Back

Next

Step 5: add payload decode

LDDS04

Serial Number: 4987441616987400 Last update: Never

Dashboard |
 History |
 Downlinks |
 Configuration |
 Debug |
 Rules |
 Permissions

General Configuration

Device Name:

Location: Optional

Tags:

Payload Decoder

Product-wide setting

When your devices sends data, the payload will be passed to the payload decoder, alongside the event's name. The payload decoder then transforms it to measurements.

```

1 = function Decoder(bytes, port) {
2   var decode = {};
3   var value=(bytes[0]<<8 | bytes[1]) & 0x3FFF;
4   decode.BatV= value/1000;
5   decode.EXT1_trigger=(bytes[0] & 0x80)? "TRUE":"FALSE";
6   decode.distance1_cm=(bytes[2]<<8 | bytes[3])/10;
7   decode.distance2_cm=(bytes[4]<<8 | bytes[5])/10;
8   decode.distance3_cm=(bytes[6]<<8 | bytes[7])/10;
9   decode.distance4_cm=(bytes[8]<<8 | bytes[9])/10;
10  decode.mes_type= bytes[10];
11
12  if(!(((bytes[0]==0x03)&&(bytes[10]==0x02))))
13  {
14    return decode;
15  }
16 }
17

```

1 → [+ Add Field](#)

Fields

Fields describe the data the device will store.

NAME	IDENTIFIER	TYPE	CURRENT VALUE	LAST UPDATE
BatV	BATV	Float	3.375	5 minutes ago
distance1_cm	DISTANCE1_CM	Float	59.3	5 minutes ago
distance2_cm	DISTANCE2_CM	Float	61.3	5 minutes ago
distance3_cm	DISTANCE3_CM	Float	58.4	5 minutes ago
distance4_cm	DISTANCE4_CM	Float	68	5 minutes ago

After added, the sensor data arrive TTN, it will also arrive and show in Datacake.

Idds04

Serial Number: 49874416169874AA Last update: Thu Sep 02 2021 11:52:15 GMT+0800

[Dashboard](#)
[History](#)
[Downlinks](#)
[Configuration](#)
[Debug](#)
[Rules](#)
[Permissions](#)
[Public Link](#)
[+ Add Widget](#)

[Desktop](#)
[Mobile](#)

1 → [+ Add Widget](#)
2 → [+ Add Widget](#)

Boolean
Displays a boolean state

Chart
Displays a chart

Headline
Displays a headline

Histogram
Displays a histogram

Map
Displays a map

Text
Displays a text widget

Value
Displays a measurement

Switch
Displays a switch widget

Slider
Displays a slider

Downlink
Button that sends a message to a device

Image
Displays a static image

Edit Value Widget

New Value Widget **0**

1

Basics **Data** Appearance Gauge Timeframe

Field

Please Select

- Please Select
- BatV
- distance1_cm
- distance2_cm
- distance3_cm
- distance4_cm

2

3

Cancel Save

Idds04

Serial Number: 49874416169874AA | Last update: Thu Sep 02 2021 11:52:15 GMT+0800

Dashboard | History | Downlinks | Configuration | Debug | Rules | Permissions | Public Link | Add Widget

Desktop | Mobile | More

BatV a few seconds ago	3.38	distance1_cm a few seconds ago	59.3	distance2_cm a few seconds ago	61.3
		distance3_cm a few seconds ago	57.1	distance4_cm a few seconds ago	70

2.7 Frequency Plans

The LDDS04 uses OTAA mode and below frequency plans by default. If user want to use it with different frequency plan, please refer the AT command sets.

2.7.1 EU863-870 (EU868)

Uplink:

868.1 - SF7BW125 to SF12BW125
868.3 - SF7BW125 to SF12BW125 and SF7BW250
868.5 - SF7BW125 to SF12BW125
867.1 - SF7BW125 to SF12BW125
867.3 - SF7BW125 to SF12BW125
867.5 - SF7BW125 to SF12BW125
867.7 - SF7BW125 to SF12BW125
867.9 - SF7BW125 to SF12BW125
868.8 - FSK

Downlink:

Uplink channels 1-9 (RX1)
869.525 – SF12BW125 (RX2 downlink only)

2.7.2 US902-928(US915)

Used in USA, Canada, and South America. Frequency band as per definition in LoRaWAN 1.0.3 Regional document.

To make sure the end node supports all sub band by default. In the OTAA Join process, the end node will use frequency 1 from sub-band1, then frequency 1 from sub-band2, then frequency 1 from sub-band3, etc to process the OTAA join.

After Join success, the end node will switch to the correct sub band by:

- Check what sub-band the LoRaWAN server ask from the OTAA Join Accept message and switch to that sub-band
- Use the Join successful sub-band if the server doesn't include sub-band info in the OTAA Join Accept message (TTN v2 doesn't include)

2.7.3 CN470-510 (CN470)

Used in China, Default use CHE=1

Uplink:

486.3 - SF7BW125 to SF12BW125
486.5 - SF7BW125 to SF12BW125
486.7 - SF7BW125 to SF12BW125
486.9 - SF7BW125 to SF12BW125
487.1 - SF7BW125 to SF12BW125
487.3 - SF7BW125 to SF12BW125
487.5 - SF7BW125 to SF12BW125
487.7 - SF7BW125 to SF12BW125

Downlink:

506.7 - SF7BW125 to SF12BW125
506.9 - SF7BW125 to SF12BW125
507.1 - SF7BW125 to SF12BW125
507.3 - SF7BW125 to SF12BW125
507.5 - SF7BW125 to SF12BW125

507.7 - SF7BW125 to SF12BW125
507.9 - SF7BW125 to SF12BW125
508.1 - SF7BW125 to SF12BW125
505.3 - SF12BW125 (RX2 downlink only)

2.7.4 AU915-928(AU915)

Frequency band as per definition in LoRaWAN 1.0.3 Regional document.

To make sure the end node supports all sub band by default. In the OTAA Join process, the end node will use frequency 1 from sub-band1, then frequency 1 from sub-band2, then frequency 1 from sub-band3, etc to process the OTAA join.

After Join success, the end node will switch to the correct sub band by:

- Check what sub-band the LoRaWAN server ask from the OTAA Join Accept message and switch to that sub-band
- Use the Join successful sub-band if the server doesn't include sub-band info in the OTAA Join Accept message (TTN v2 doesn't include)

2.7.5 AS920-923 & AS923-925 (AS923)

Default Uplink channel:

923.2 - SF7BW125 to SF10BW125
923.4 - SF7BW125 to SF10BW125

Additional Uplink Channel:

(OTAA mode, channel added by JoinAccept message)

AS920~AS923 for Japan, Malaysia, Singapore:

922.2 - SF7BW125 to SF10BW125
922.4 - SF7BW125 to SF10BW125
922.6 - SF7BW125 to SF10BW125
922.8 - SF7BW125 to SF10BW125
923.0 - SF7BW125 to SF10BW125
922.0 - SF7BW125 to SF10BW125

AS923 ~ AS925 for Brunei, Cambodia, Hong Kong, Indonesia, Laos, Taiwan, Thailand, Vietnam:

923.6 - SF7BW125 to SF10BW125
923.8 - SF7BW125 to SF10BW125
924.0 - SF7BW125 to SF10BW125
924.2 - SF7BW125 to SF10BW125
924.4 - SF7BW125 to SF10BW125
924.6 - SF7BW125 to SF10BW125

Downlink:

Uplink channels 1-8 (RX1)
923.2 - SF10BW125 (RX2)

2.7.6 KR920-923 (KR920)

Default channel:
922.1 - SF7BW125 to SF12BW125

922.3 - SF7BW125 to SF12BW125

922.5 - SF7BW125 to SF12BW125

Uplink: (OTAA mode, channel added by JoinAccept message)

922.1 - SF7BW125 to SF12BW125

922.3 - SF7BW125 to SF12BW125

922.5 - SF7BW125 to SF12BW125

922.7 - SF7BW125 to SF12BW125

922.9 - SF7BW125 to SF12BW125

923.1 - SF7BW125 to SF12BW125

923.3 - SF7BW125 to SF12BW125

Downlink:

Uplink channels 1-7(RX1)

921.9 - SF12BW125 (RX2 downlink only; SF12BW125 might be changed to SF9BW125)

2.7.7 IN865-867 (IN865)

Uplink:

865.0625 - SF7BW125 to SF12BW125

865.4025 - SF7BW125 to SF12BW125

865.9850 - SF7BW125 to SF12BW125

Downlink:

Uplink channels 1-3 (RX1)

866.550 - SF10BW125 (RX2)

2.8 LED Indicator

The LDDS04 has an internal LED which is used to show the status of different state.

- After LDDS04 is turned on, if the 4 channels converter is detected, the LED will **flash 4 times quickly**.
- **Blink once** when device transmit a packet.
- Solid ON for **Five Seconds** when OTAA Join Successfully.

2.9 Firmware Change Log

Firmware download link:

http://www.dragino.com/downloads/index.php?dir=LoRa_End_Node/LDDS04/Firmware/

Firmware Upgrade Method:

http://wiki.dragino.com/index.php?title=Firmware_Upgrade_Instruction_for_STM32_base_products#Introduction

3. Configure LDDS04 via AT Command or LoRaWAN Downlink

Use can configure LDDS04 via AT Command or LoRaWAN Downlink.

- AT Command Connection: See [FAQ](#).
- LoRaWAN Downlink instruction for different platforms:
http://wiki.dragino.com/index.php?title=Main_Page#Use_Note_for_Server

There are two kinds of commands to configure LDDS04, they are:

- **General Commands.**

These commands are to configure:

- ✓ General system settings like: uplink interval.
- ✓ LoRaWAN protocol & radio related command.

They are same for all Dragino Device which support DLWS-005 LoRaWAN Stack. These commands can be found on the wiki:

http://wiki.dragino.com/index.php?title=End_Device_Downlink_Command

- **Commands special design for LDDS04**

These commands only valid for LDDS04, as below:

3.1 Set Transmit Interval Time

Feature: Change LoRaWAN End Node Transmit Interval.

AT Command: AT+TDC

Command Example	Function	Response
AT+TDC=?	Show current transmit Interval	30000 OK the interval is 30000ms = 30s
AT+TDC=60000	Set Transmit Interval	OK Set transmit interval to 60000ms = 60 seconds

Downlink Command: 0x01

Format: Command Code (0x01) followed by 3 bytes time value.

If the downlink payload=0100003C, it means set the END Node's Transmit Interval to 0x00003C=60(S), while type code is 01.

- Example 1: Downlink Payload: 0100001E // Set Transmit Interval (TDC) = 30 seconds
- Example 2: Downlink Payload: 0100003C // Set Transmit Interval (TDC) = 60 seconds

3.2 Set Interrupt Mode

Feature, Set Interrupt mode for GPIO_EXIT.

AT Command: AT+INTMOD

Command Example	Function	Response
AT+INTMOD=?	Show current interrupt mode	0 OK the mode is 0 = No interruption
AT+INTMOD=2	Set Transmit Interval 0- (Disable Interrupt), 1- (Trigger by rising and falling edge), 2- (Trigger by falling edge) 3- (Trigger by rising edge)	OK

Downlink Command: 0x06

Format: Command Code (0x06) followed by 3 bytes.

This means that the interrupt mode of the end node is set to 0x000003=3 (rising edge trigger), and the type code is 06.

- Example 1: Downlink Payload: 06000000 // Turn off interrupt mode
- Example 2: Downlink Payload: 06000003 // Set the interrupt mode to rising edge trigger

3.3 Get Firmware Version Info

Feature: use downlink to get firmware version.

Downlink Command: 0x26


Downlink Control Type	FPort	Type Code	Downlink payload size(bytes)
Get Firmware Version Info	Any	26	2

- Reply to the confirmation package: 26 01
- Reply to non-confirmed packet: 26 00

Device will send an uplink after got this downlink command. With below payload:

Configures info payload:

Size (bytes)	1	1	1	2	1	4	1
Value	Software Type	Frequency Band	Sub-band	Firmware Version	Sensor Type	Reserve	Message Type Always 0x02



LDDs04
ID: ldd04

Created 46 minutes ago

Last seen 33 seconds ago ↑ 6 ↓ 3

Overview
Live data
Messaging
Location
Payload formatters
Claiming
General settings

Time	Type	Data preview	Frequency Band	Firmware Version	Sensor Type
↑ 15:17:36	Forward uplink data message	Payload: { } 03 01 FF 10 00 08 FF FF ...			
↑ 15:17:31	Forward uplink data message	Payload: { BatV: 3.393, EXTi_Trigger: "TRUE", distance1_cm: 79.1, distance2_cm: 79.1, distance3_cm: 0, distance4_cm: 78.9 } 80			
↓ 15:17:29	Forward downlink data message	FPort: 2 Payload: 26 01			
↑ 15:04:08	Forward uplink data message				

Software Type: Always 0x03 for LDDs04

Frequency Band:

- *0x01: EU868
- *0x02: US915
- *0x03: IN865
- *0x04: AU915
- *0x05: KZ865
- *0x06: RU864
- *0x07: AS923
- *0x08: AS923-1
- *0x09: AS923-2
- *0xa0: AS923-3

Sub-Band: value 0x00 ~ 0x08

Firmware Version: 0x0100, Means: v1.0.0 version

Sensor Type:

- 0x01: LSE01
- 0x02: LDDs75
- 0x03: LDDs20
- 0x04: LLMS01
- 0x05: LSPH01
- 0x06: LSNPK01
- 0x07: LLDS12
- 0x08: LDDs04


4. Battery & how to replace

4.1 Battery Type

LDDs04 is equipped with a [8500mAH ER26500 Li-SOCI2 battery](#). The battery is un-rechargeable battery with low discharge rate targeting for 8~10 years use. This type of battery is commonly used in IoT target for long-term running, such as water meter.

The discharge curve is not linear so can't simply use percentage to show the battery level. Below is the battery performance.

1. Typical discharge profile at +20 °C (Typical value)



Minimum Working Voltage for the LDDS04:
LDDS04: 2.45v ~ 3.6v

4.2 Replace Battery

Any battery with range 2.45 ~ 3.6v can be a replacement. We recommend to use Li-SOCI2 Battery. And make sure the positive and negative pins match.

4.3 Power Consumption Analyze

Dragino Battery powered product are all runs in Low Power mode. We have an update battery calculator which base on the measurement of the real device. User can use this calculator to check the battery life and calculate the battery life if want to use different transmit interval.


Instruction to use as below:

Step 1: Downlink the up-to-date DRAGINO_Battery_Life_Prediction_Table.xlsx from:
https://www.dragino.com/downloads/index.php?dir=LoRa_End_Node/Battery_Analyze/

Step 2: Open it and choose

- Product Model
- Uplink Interval
- Working Mode

And the Life expectation in difference case will be shown on the right.



The battery related documents as below:

- [Battery Dimension](#),
- [Lithium-Thionyl Chloride Battery](#) datasheet, [Tech Spec](#)
- [Lithium-ion Battery-Capacitor](#) datasheet, [Tech Spec](#)



4.3.1 Battery Note

The Li-SiCO battery is designed for small current / long period application. It is not good to use a high current, short period transmit method. The recommended minimum period for use of this battery is 5 minutes. If you use a shorter period time to transmit LoRa, then the battery life may be decreased.

4.3.2 Replace the battery

You can change the battery in the LDDS04. The type of battery is not limited as long as the output is between 3v to 3.6v. On the main board, there is a diode (D1) between the battery and the main circuit. If you need to use a battery with less than 3.3v, please remove the D1 and shortcut the two pads of it so there won't be voltage drop between battery and main board.

The default battery pack of LDDS04 includes a ER26500 plus super capacitor. If user can't find this pack locally, they can find ER26500 or equivalence, which will also work in most case. The SPC can enlarge the battery life for high frequency use (update period below 5 minutes)

5. Use AT Command

5.1 Access AT Commands

LDDS04 supports AT Command set in the stock firmware. You can use a USB to TTL adapter to connect to LDDS04 for using AT command, as below.




Connection:

USB TTL GND <----> GND

USB TTL TXD <----> UART_RXD

USB TTL RXD <----> UART_TXD

In the PC, you need to set the serial baud rate to **9600** to access the serial console for LDDS04. LDDS04 will output system info once power on as below:



Valid AT Command please check [Configure Device](#).

6. FAQ

6.1 How to change the LoRa Frequency Bands/Region

You can follow the instructions for [how to upgrade image](#).

When downloading the images, choose the required image file for download.

7. Trouble Shooting

7.1 AT Commands input doesn't work

In the case if user can see the console output but can't type input to the device. Please check if you already include the **ENTER** while sending out the command. Some serial tool doesn't send **ENTER** while press the send key, user need to add ENTER in their string.

8. Order Info

8.1 Main Device LDDS04

Part Number: **LDDS04-XX**

XX: The default frequency band

- **AS923**: LoRaWAN AS923 band
- **AU915**: LoRaWAN AU915 band
- **EU433**: LoRaWAN EU433 band
- **EU868**: LoRaWAN EU868 band
- **KR920**: LoRaWAN KR920 band
- **US915**: LoRaWAN US915 band
- **IN865**: LoRaWAN IN865 band
- **CN470**: LoRaWAN CN470 band

8.2 Probe Model

Detail See [Probe Option](#) Section

- A01A-15
- A02-15
- A13-15
- A16-15

9. Packing Info

Package Includes:

- LDDS04 LoRaWAN 4-Channels Distance Sensor x 1
- Exclude probes.

Dimension and weight:

- Device Size: cm
- Device Weight: g
- Package Size / pcs : cm
- Weight / pcs : g

10. Support

- Support is provided Monday to Friday, from 09:00 to 18:00 GMT+8. Due to different timezones we cannot offer live support. However, your questions will be answered as soon as possible in the before-mentioned schedule.
- Provide as much information as possible regarding your enquiry (product models, accurately describe your problem and steps to replicate it etc) and send a mail to

support@dragino.com