



LoRaWAN[®] Solenoid Valve Controller

UC51x Series

User Guide




Safety Precautions

Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- ❖ The device must not be remodeled in any way.
- ❖ Do not place the device close to objects with naked flames.
- ❖ Do not place the device where the temperature is below/above the operating range.
- ❖ Make sure electronic components do not drop out of the enclosure while opening.
- ❖ When installing the battery, please install it accurately, and do not install the reverse or wrong model.
- ❖ The device must never be subjected to shocks or impacts.


Declaration of Conformity

UC51x series is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



Copyright©2011-2022 Milesight. All rights reserved.

All information in this guide is protected by copyright law. Whereby, no organization or individual shall copy or reproduce the whole or part of this user guide by any means without written authorization from Xiamen Milesight IoT Co., Ltd.



For assistance, please contact
Milesight technical support:
Email: iot.support@milesight.com
Tel: 86-592-5085280
Fax: 86-592-5023065
Address: Building C09, Software Park III,
Xiamen 361024, China

Revision History

Date	Doc Version	Description
Feb. 20, 2021	V 1.0	Initial version
Nov.26, 2021	V 1.1	Description Update
Dec. 9, 2021	V 2.0	Update based on 2.0 hardware

Contents

1. Product Introduction.....	4
1.1 Overview.....	4
1.2 Features.....	4
2. Hardware Introduction.....	4
2.1 Packing List.....	4
2.2 Hardware Overview.....	5
2.3 Power Button.....	5
2.4 Dimensions.....	6
3. Operation Guide.....	6
3.1 Log in the ToolBox.....	6
3.1.1 NFC Configuration.....	6
3.1.2 USB Configuration.....	7
3.2 Solenoid Valve Control.....	8
3.3 LoRaWAN Settings.....	9
3.4 Solenoid Settings.....	11
3.5 Maintenance.....	13
3.5.1 Upgrade.....	13
3.5.2 Backup.....	14
3.5.3 Reset to Factory Default.....	15
4. Installation.....	16
5. Milesight IoT Cloud Management.....	17
5.1 Add UC51x to Cloud.....	17
5.2 Solenoid Valve Control.....	19
6. Device Payload.....	21

1. Product Introduction

1.1 Overview

UC51x series LoRaWAN® wireless solenoid valve controller is a device used to remotely control DC latching solenoids of the valve. It contains 2 solenoid interfaces and 1 pulse interface, which can be easily controlled locally or remotely.

Besides ultra-low-power LoRaWAN® technology, UC51x series also provides both solar and built-in battery power supply for uninterrupted operation. For outdoor applications, it equips with IP67-rated enclosure and M12 connectors to protect from water and dust under harsh environments.

1.2 Features

- Compatible with standard DC latching solenoids
- OPEN/CLOSE control by mobile App locally or commands remotely
- Two pulse water meter interfaces for flow monitoring
- Transmission distance up to 15 km with line of sight
- Waterproof design including IP67 case and M12 connectors
- Solar powered and built-in chargeable battery
- Quick wireless configuration via NFC
- Time and flow control via Milesight IoT Cloud

2. Hardware Introduction


2.1 Packing List



1 × UC51x
Device




2 × Data Cables
(1.5 m)



1 × Mounting
Bracket



4 × Wall
Mounting Kits



2 × Hose Clamps




1 × Fixing Screw



1 × Quick Guide



1 × Warranty Card




1 × Solar Panel Kit
(Optional for UC511)




If any of the above items is missing or damaged, please contact your sales Representative.

2.2 Hardware Overview



Interface 1&2:

Pin	Description
1	DC+/OUT1 (Red)
2	DC-/OUT2 (Black)
3	GND
4	INSERT BOOT*
5	GND
6	GPIO




* Please refer to “Solenoid Valve Wiring Switch” item in [section 3.4](#).

2.3 Power Button

Function	Action	LED Indication
Turn On	Press and hold the button for more than 3s.	Off → On
Turn Off	Press and hold the button for more than 3s.	On → Off
Reset	Press and hold the button for more than 10s.	Blinks.
Check On/Off Status	Quickly press the power button.	Light On: Device is on.
		Light Off: Device is off.

2.4 Dimensions (mm)



3. Operation Guide

3.1 Log in the ToolBox

UC51x series can be monitored and configured via ToolBox App or ToolBox software. Please select one of them to complete configuration.

3.1.1 NFC Configuration

1. Download and install “Milesight ToolBox” App from Google Play or Apple App Store.
2. Enable NFC on the smartphone and launch Milesight ToolBox.
3. Attach the smartphone with NFC area to the device to read basic information.
4. Basic information and settings of devices will be shown on ToolBox if it’s recognized successfully. You can turn on/off the device by tapping the button on the Device Status. In order to protect the security of devices, password validation is required when first configuration. Default password is **123456**.



5. Tap “Read” button to check current status of device.
6. Tap “Write” button to write all your settings to the device.

Note:


- 1) Ensure the location of smartphone NFC area and it’s recommended to take off phone case.
- 2) If the smartphone fails to read/write configurations via NFC, keep the phone away and back

to try again.

3) UC51x series can also be configured by dedicated NFC reader, which can be purchased from Milesight IoT.

3.1.2 USB Configuration

1. Download ToolBox from [Milesight IoT website](#).
2. Open the case of UC51x and connect the UC51x to computer via type-C port.



3. Open the ToolBox and select type as "General", then click password to log in ToolBox. (Default password: **123456**)

The screenshot shows a 'ToolBox Settings' dialog box with the following fields:

Type	General
Serial port	COM4
Login password	
Baud rate	115200
Data bits	8
Parity bits	None
Stop bits	1

At the bottom of the dialog are 'Save' and 'Cancel' buttons.

4. After logging in the ToolBox, you can click "Power On" or "Power Off" to turn on/off device and change other settings.

The screenshot shows the ToolBox interface with a sidebar on the left containing 'Status', 'LoRaWAN Settings', 'Device Settings', and 'Maintenance'. The main area displays the 'Status' page for a UC512-DI-868M device. A 'Power On' button is visible in the top right corner.

Status >	
Model:	UC512-DI-868M
Serial Number:	6415A51585070020
Device EUI:	24e124415a515850
Firmware Version:	01.08
Hardware Version:	1.0
Device Status:	Off
Join Status:	-
RSSI/SNR:	-
Valve1 Status:	-
Counter1:	-
Valve2 Status:	-
Counter2:	-
Battery:	-
Channel Mask:	-
Uplink Frame-counter:	-

3.2 Solenoid Valve Control

Solenoid valve can be controlled by ToolBox App or ToolBox software locally.

Via ToolBox Software:

Click "Open" or "Close" button on the "Status" page to change the status of solenoid valves.

Status > Power Off

Model:	UC512-DI-868M
Serial Number:	6415A51585070020
Device EUI:	24e124415a515850
Firmware Version:	01.08
Hardware Version:	1.0
Device Status:	On
Join Status:	Activate
RSSI/SNR:	-42/6
Valve1 Status:	Close Open
Counter1:	-
Valve2 Status:	Open Close
Counter2:	-
Battery:	100%
Channel Mask:	0007
Uplink Frame-counter:	189

Via ToolBox App:

Click buttons of Valve Status on the "Device -> Status" page, then attach the smart phone to device to change the status of solenoid valves.

Status	Setting	Reset
Hardware Version		V1.0
Device Status	ON	<input checked="" type="checkbox"/>
Join Status	Activated	
RSSI/SNR		-35/15
Device Time	2021-02-04 10:35	Sync
Valve 1 Status	Off	<input type="checkbox"/>
Counter 1		0
Valve 2 Status	On	<input checked="" type="checkbox"/>
Counter 2		0
Battery		100%

3.3 LoRaWAN Settings

LoRaWAN settings is used for configuring the transmission parameters in LoRaWAN® network.

Step 1: Go to “**LoRaWAN -> Basic**” of ToolBox software or “**Setting -> LoRaWAN Settings**” of ToolBox App to configure join type, App EUI, App Key and other information. You can also keep all settings by default.

Device EUI	<input type="text" value="24E124415A515850"/>
App EUI	<input type="text" value="24E124C0002A0001"/>
Application Port	<input type="text" value="85"/>
Join Type	<input type="text" value="OTAA"/>
LoRaWAN Version	<input type="text" value="V1.1.0"/>
Application Key	<input type="text" value="*****"/>
Spread Factor	<input type="text" value="SF10-DR2"/>
Confirmed Mode	<input type="checkbox"/>
Rejoin Mode	<input checked="" type="checkbox"/>
Set the number of packets sent	<input type="text" value="32"/> packets
ADR Mode	<input checked="" type="checkbox"/>
TXPower	<input type="text" value="TXPower0-16 dBm"/>

Parameters	Description
Device EUI	Unique ID of the device which can also be found on the label.
App EUI	Default App EUI is 24E124C0002A001.
Application Port	The port used for sending and receiving data, default port is 85.
Join Type	OTAA and ABP mode are available.
LoRaWAN Version	V1.0.2, V1.0.3, V1.1 are available.
Application Key	Appkey for OTAA mode, default is 5572404C696E6B4C6F52613230313823.
Device Address	DevAddr for ABP mode, default is the 5 th to 12 th digits of SN.
Network Session Key	Nwkskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Application Session Key	Appskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Spread Factor	If ADR is disabled, the device will send data via this spread factor.
Confirmed Mode	If the device does not receive ACK packet from network server, it will resend

	data 3 times at most.
Rejoin Mode	Reporting interval \leq 30 mins: the device will send specific mounts of LoRaMAC packets to check connection status every 30 mins; If no reply after specific packets, the device will re-join. Reporting interval $>$ 30 mins: the device will send specific mounts of LoRaMAC packets every to check connection status every reporting interval; If no reply after specific packets, the device will re-join.
ADR Mode	Allow network server to adjust datarate of the device.
Tx Power	Tx power of the device.

Note:

- 1) Please contact sales for device EUI list if there are many units.
- 2) Please contact sales if you need random App keys before purchase.
- 3) Select OTAA mode if you use Milesight IoT cloud to manage devices.
- 4) Only OTAA mode supports rejoin mode.

Step 2: Go to “LoRaWAN -> Channel” of ToolBox software or “Setting -> LoRaWAN Settings” of ToolBox APP to select supported frequency and select channels to send uplinks. Make sure the channels match the LoRaWAN® gateway.

Support Frequency : EU868				
<input type="checkbox"/>	Index	Frequency/MHz	Max Datarate	Min Datarate
<input checked="" type="checkbox"/>	0	868.1	5-SF7BW125	0-SF12BW125
<input checked="" type="checkbox"/>	1	868.3	5-SF7BW125	0-SF12BW125
<input checked="" type="checkbox"/>	2	868.5	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	3	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	4	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	5	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	6	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	7	0	5-SF7BW125	0-SF12BW125

If frequency is one of CN470/AU915/US915, you can enter the index of the channel that you want to enable in the input box, making them separated by commas.

Examples:

1, 40: Enabling Channel 1 and Channel 40

1-40: Enabling Channel 1 to Channel 40

1-40, 60: Enabling Channel 1 to Channel 40 and Channel 60

All: Enabling all channels

Null: Indicates that all channels are disabled

Support Frequency :

Enabled Channel Index:

Channel Index	Frequency/MHz	Channel Spacing/MHz	BW/kHz
0 - 15	915.2 - 918.2	0.2	125
16 - 31	918.4 - 921.4	0.2	125
32 - 47	921.6 - 924.6	0.2	125
48 - 63	924.8 - 927.8	0.2	125
64 - 71	915.9 - 927.1	1.6	500

Note:

For -868M model, default frequency is EU868;

For -915M model, default frequency is AU915.

3.4 Solenoid Settings

Go to “**General -> Device Settings -> Basic**” of ToolBox software or “**Setting -> General Settings**” of ToolBox App to change the reporting configurations.

Device Type

Reporting Interval min

Solenoid Valve Wiring Switch

Data Reporting

Device Return to Power Supply State

Class Type

Response Time s

Change Password

Parameters	Description
Reporting Interval	Reporting interval of transmitting data to network server. Default: 20min, Range: 1-1080 mins.
Solenoid Valve Wiring Switch	After this parameter is enabled, when users connect the solenoid cable to any solenoid interface, the device will turn on automatically.
Data Reporting	Select the contents to report to network server. All: Report all interface status; Valve 1 & Water Meter 1: Report the status of the Valve 1 interface and data of GPIO1; Valve 2 & Water Meter 2: Report the status of the Valve 2 interface and data of GPIO2.
Device returns to the power supply state	If the device loses power and return to power supply, the device will be on or off according to this parameter.
Class Type	Working mode of LoRaWAN [®] device. UC511: Class A, Class B and Class C are available; UC512: Class A and Class B are available.
Response Time	When the device works under Class A mode, it only receives control commands every reporting interval comes. In order to shorten the delay time of control, the device will send blank package to allow to receive the control commands every Response Time interval. Note: The shorter the response time, the shorter the battery life.
Ping Slot Periodicity	When the device works under Class B mode, set the interval to open the reception window.
Change Password	Change the password for ToolBox App or software to read/write this device.

Note:

- 1) When device connects to network server of Milesight gateway, the blank package will take up the frame count but not show on the package list.
- 2) Reboot or re-join will not affect the counting.

3.5 Maintenance

3.5.1 Upgrade

ToolBox Software:

1. Download firmware from www.milesight-iot.com to your PC.
2. Go to “**Maintenance -> Upgrade**” of ToolBox software, click “**Browse**” to import firmware and upgrade the device. You can also click “**Up to Date**” to search for the latest firmware of the device and upgrade.

Maintenance >

The screenshot shows the 'Upgrade' tab selected in the 'Maintenance' section. The interface displays the following information and controls:

Model:	UC512-DI-868M
Firmware Version:	01.08
Hardware Version:	1.0
Domain:	Beijing Server
FOTA:	<input type="button" value="Up to date"/> Your device is up to date.
Update Locally:	<input type="text"/> <input type="button" value="Browse"/> <input type="button" value="Upgrade"/>

ToolBox App:

1. Download firmware from www.milesight-iot.com to your smartphone.
2. Open ToolBox App and click “Browse” to import firmware and upgrade the device.

Note:

- 1) Operation on ToolBox is not supported during the upgrade.
- 2) Only Android version ToolBox supports the upgrade feature.

UC512-DI-868M		
Status	Setting	Maintenance
SN	6415A51585070020	
Model	UC512-DI-868M	
Firmware Version	V1.12	
Hardware Version	V1.0	
Manual Upgrade		
<input type="button" value="Browse"/>		

3.5.2 Backup

UC51x devices support configuration backup for easy and quick device configuration in bulk.

Backup is allowed only for devices with the same model and LoRa frequency band. Please select one of following methods to backup device:


ToolBox Software:

1. Go to **"Maintenance -> Backup and Reset"**, click "Export" to save current configuration as json format backup file.
2. Click "Browse" to select backup file, then click "Import" to import the configurations.

Upgrade	Backup and Reset	
Config Backup	<input type="button" value="Export"/>	
Config File	<input type="text"/>	<input type="button" value="Browse"/> <input type="button" value="Import"/>
Restore Factory Defaults	<input type="button" value="Reset"/>	

ToolBox App:

1. Go to "Template" page on the App and save current settings as a template. You can also edit the template file.
2. Select this template and attach to another device to write configuration.




3.5.3 Reset to Factory Default

Please select one of following methods to reset device:

Via Hardware: Open the case of UC51x and hold on power button more than 10s.

Via ToolBox Software: Go to **"Maintenance -> Backup and Reset"** to click **"Reset"**.



Via ToolBox App: Go to **"Device -> Maintenance"** to click **"Reset"**, then attach smart phone with NFC area to UC51x to complete reset.

☰ **UC512-DI-868M**

StatusSettingMaintenance

SN	6415A51585070020
Model	UC512-DI-868M
Firmware Version	V1.12
Hardware Version	V1.0

Manual Upgrade

Browse

Restore Factory Default


Reset

4. Installation

UC51x series support wall mounting or pole mounting. Before installation, make sure you have the mounting bracket, wall or pole mounting kits and other required tools.

Wall Mounting:

1. Fix the wall plugs into the wall, then fix the mounting bracket to the wall plugs with screws.
2. Put the device on the mounting bracket, then fix the bottom of the device to the bracket with a fixing screw.




Pole Mounting:

1. Straighten out the hose clamp and slide it through the rectangular rings in the mounting bracket, wrap the hose clamp around the pole. After that use a screwdriver to tighten the locking mechanism by

turning it clockwise.

2. Put the device on the mounting bracket, then fix the bottom of the device to the bracket with a fixing screw.




5. Milesight IoT Cloud Management

UC51x series can be managed by Milesight IoT Cloud platform. Milesight IoT cloud is a comprehensive platform that provides multiple services including device remote management and data visualization with the easiest operation procedures. Please register a Milesight IoT Cloud account before operating following steps.

5.1 Add UC51x to Cloud

1. Ensure Milesight LoRaWAN[®] gateway is online in Milesight IoT Cloud. For more info about connecting gateway to cloud please refer to gateway's user guide.



2. Go to "My Devices" page and click "+New Devices". Fill in the SN of UC51x and select associated gateway.

Add Device [X]

* SN: 6415A51585070020

* Name: UC511

* Associated Gateway: UG Gateway

* Device EUI: 24e124415A515850

* Application Key: 5572404c696e6b4c6f52613230313823

Cancel Confirm

3. Click and go to “Basic Settings” to change class type the same as device settings.

Devices / UC511 / Basic Settings

Basic Settings | Interface Settings | Maintenance | Log

Refresh Share

* Name: UC511

* Application Key: 5572404c696e6b4c6f52613230313823

LoRaWAN Class ⓘ: classA

Class A: Downlink communications (configuration changes) from the Cloud at any other time will have to wait until the next scheduled uplink from devices.

Description:

Besides, configure the unit of per pulse if you connect the water meter.

Devices / UC511 / Basic Settings

Basic Settings | Interface Settings | Maintenance | Log

Refresh Share


Description:

* Unit Per Pulse: 1 gal

* Reporting Interval ⓘ: 20 min


Device Offline Alarm:


4. Click and go to “Interface Settings” to select used interfaces and customize the name and thresholds.




5.2 Solenoid Valve Control

Solenoid valve can be controlled by Milesight IoT cloud webpage or App.


1. Click  to open the solenoid valve and configure the duration.



You can also add a switch on the dashboard to control the status of solenoid valves.




Note: If the working mode of UC51x is LoRaWAN Class A, control commands will delay until the time icon disappears.



2. Go to "Triggers" page to add actions to trigger the solenoid valve to open for a period of time or a specific volume of water.

Note: Water volume control is only worked when you connect water meter to UC51x device.



6. Device Payload

UC51x Series use the standard Milesight IoT payload format based on IPSO. Please refer to the ***UC51x Series Communication Protocol***; for decoders of Milesight IoT products please click [here](#).

-END-