

Sontex 56x & 8x8

Installation Guide

Sontex your link to innovative metering

Scoop of delivery

Product description

Mounting and commissioning instructions

General

The heat cost allocator is an approved precision measuring instrument for the allocation of heating costs and must be handled with care. The Sontex heat cost allocator range complies with the requirements of the European directive EN 834:2013.

The heat cost allocator must be operated under the specified operating conditions. The seal must remain intact. If the heat cost allocator is used outside of these conditions, the manufacturer's liability is excluded and the factory warranty and metrological conformity are no longer guaranteed.

Electronic heat cost allocators cannot be used with steam heating, floor heating, ceiling radiant heaters, flap-controlled radiators and electrical radiator.

In case of combined valve- and flap-controlled radiators, the installation of an electronic heat cost allocator is only permitted if the flap control is dismounted or maintained in position "open".

Convector heaters where the performance can be altered by an electric blower as well as heat towel racks with an electric heating cartridge may only be equipped with an electronic heat cost allocator if the additional electric attachments are dismounted or shut down.

The heat cost allocator is an electronic device which – like all other similar devices – has to be handled with care. It is sensible to be electric discharge and contacting certain areas of the PCB. Electric discharge can destroy the device or – even worse – damage it in a way that it fails after an indefinite period of time. For this reason it is essential in any case to avoid contact with the PCB.

Heat cost allocators may only be installed or replaced by qualified personnel.

Before mounting

- Before installation, check that the unit has not been damaged.
- Don't let it fall
- If the heat cost allocator has fallen off, it must not be reinstalled.

Safety with Lithium batteries

Lithium batteries are used, some safety rules must be observed. In particular, replacement of the batteries is not allowed. When recycling the device, please observe the following points: Do not recharge or short-circuit them, protect them from moisture or strong heat exposure, do not throw them into fire and keep them out of reach of children.

Mounting

Mounting position

The mounting position on the radiator is directly related to the type of radiator, its heat output and the heat cost allocator. To ensure correct data acquisition, the heat cost allocators must be installed and operated in a certain position in accordance with the regulations.

The heat radiation from the radiator is transmitted directly to the temperature sensor or remote sensor of the heat cost allocator via the mounting plate.

Sontex 56x & 8x8

Installation Guide

Normal mode

- Transmission interval each 120 seconds (minimum)
- Periodic 12h / day (programmable), 5 / 7 days

Readout over the short telegram (OMS compliant)

Installation mode

- Radio availability 24h / 24h
- Transmission interval each 30 seconds

Normal mode

- Transmission interval each 120 seconds (minimum)
- 24h / 24h, 7 / 7 days

Type of telegram must be defined when ordering.

Operation mode LoRaWAN-class A (878)

Installation mode

- In this mode, the connection procedure (JOIN) is initiated automatically. The JOIN procedure is repeated once a day if the network connection cannot be established. Depending on the reception quality in the network, the heat cost allocator automatically determines the sending of a short or long telegram. The sending intervals correspond to the values programmed in the device.

Normal mode

- Depending on the reception quality in the network, the heat cost allocator automatically determines the sending of a short or long telegram. The sending intervals correspond to the values programmed in the device.

Automatic commissioning (by default)

General remarks:

- The welding gap for M3 threaded bolts must be 50 mm. Before welding, the paint on the welding points must be scraped off. Weld the bolts on a surface or groove containing water.
- Use only M3 threaded bolts with a maximum length of 8mm or there is a risk of damaging the heat cost allocator.
- It is not possible to weld on aluminum radiators.
- On radiators with an even number of sections, the heat cost allocator has to be mounted between the center sections.
- On radiators with an odd number of sections, the heat cost allocator has to be mounted between the two sections following the central section in the forward direction.
- Mount the back plate through the 2 oval holes and fit it to the top edge.

For more information about mounting on different types of radiators and fasteners please contact your local Sontex agent.

Mounting of the remote sensor

For each version of heat cost allocator, it is possible to plug the connector of the remote sensor into an interface inside the heat cost allocator. The remote sensor will be automatically detected by the heat cost allocator.

Once equipped with a remote sensor, the heat cost allocator will only work for an application with remote sensor. Remote sensor version with 2 m or 5 m cable. The cable includes a stopper-knot.

In case of combined valve- and flap-controlled radiators, the installation of an electronic heat cost allocator is only permitted if the flap control is dismounted or maintained in position "open".

Convector heaters where the performance can be altered by an electric blower as well as heat towel racks with an electric heating cartridge may only be equipped with an electronic heat cost allocator if the additional electric attachments are dismounted or shut down.

The heat cost allocator is an electronic device which – like all other similar devices – has to be handled with care. It is sensible to be electric discharge and contacting certain areas of the PCB. Electric discharge can destroy the device or – even worse – damage it in a way that it fails after an indefinite period of time. For this reason it is essential in any case to avoid contact with the PCB.

Heat cost allocators may only be installed or replaced by qualified personnel.

Before mounting

- Before installation, check that the unit has not been damaged.
- Don't let it fall
- If the heat cost allocator has fallen off, it must not be reinstalled.

Safety with Lithium batteries

Lithium batteries are used, some safety rules must be observed. In particular, replacement of the batteries is not allowed. When recycling the device, please observe the following points: Do not recharge or short-circuit them, protect them from moisture or strong heat exposure, do not throw them into fire and keep them out of reach of children.

Mounting

Mounting position

The mounting position on the radiator is directly related to the type of radiator, its heat output and the heat cost allocator. To ensure correct data acquisition, the heat cost allocators must be installed and operated in a certain position in accordance with the regulations.

The heat radiation from the radiator is transmitted directly to the temperature sensor or remote sensor of the heat cost allocator via the mounting plate.

Sontex 56x & 8x8

Installationsanleitung

Sontex your link to innovative metering

Lieferumfang

Produktbeschreibung

Commissioning by pressing the push button (specify by ordering)

Transition from sleeping to installation mode is achieved by pushing the push button during 3 seconds:

The ● symbol indicates that the heat cost allocator is in installation mode.

List of the error codes

- Err.1 Manipulation (fraud). Check the fixing of the heat cost allocator on the back plate.*
- Err.2 Measurement error. Check the contact of the remote sensor.*
- Err.32 Push button constantly activated.
- Err.64 Measured temperature not within temperature range (0..105°C; 0..120°C for remote sensor).* If the error persists, please return the heat cost allocator to your Sontex agent.

Setting

The software Prog6 allows the parameterization over the optical interface.

The settings of the Sontex 878 LoRaWAN must be done with the Superprog software.

Communication Indicator

Return the heat cost allocator and plug the connector of the remote sensor into the interface inside the heat cost allocator.

Insert the remote sensor cable into the groove provided up to the slot of housing. Place the stopper-knot inside the housing. The knot will avoid any traction on the connector.

Proceed to the commissioning of the heat cost allocator on the aluminum back plate. Take care not to pinch the cable. Respect the color code of the radiator sensor and the remote sensor:

- Heat cost allocator Sontex 56 X, Sontex 566 X, Sontex 868 X and 878 X: the radiator sensor and the remote sensor are manufactured with a yellow color.
- Heat cost allocator Sontex 565, Sontex 566, Sontex 868 and Sontex 878: the radiator sensor and the remote sensor are manufactured with a white color.

LoRaWAN: When the outgoing arrow appears a JOIN request has been transmitted to the LoRaWAN network, but no response from the network has been received. If the connection could not be established, the JOIN process repeats once a day.

LoRaWAN: Incoming and outgoing arrow visible. The connection with the network is functional.

In the case of divergences, the English version takes precedence.

Technical support

For technical support contact your local Sontex agent or Sontex SA directly.

Declaration of conformity

The detailed declaration of conformity can be found and downloaded on our homepage www.sontex.ch

Hotline Sontex

support@sontex.ch
+41 32 488 30 04

Technical modifications subject to change without notice

Operation mode Radio Sontex (566)

Walk-by Radio Remote Readout

Installation mode

- Radio availability 24h / 24h

Normal mode

- Readout of the data of the heat cost allocator 566 is possible every day from 6.00 to 17.59 (winter time).

Operation mode Radio wM-Bus (868)

Readout over the long telegram for Walk-by reading

Installation mode

- Radio availability 24h / 24h
- Transmission interval each 30 seconds

Normal mode

- Transmission interval each 120 seconds (minimum)
- 24h / 24h, 7 / 7 days

Type of telegram must be defined when ordering.

Operation mode LoRaWAN-class A (878)

Installation mode

- In this mode, the connection procedure (JOIN) is initiated automatically. The JOIN procedure is repeated once a day if the network connection cannot be established. Depending on the reception quality in the network, the heat cost allocator automatically determines the sending of a short or long telegram. The sending intervals correspond to the values programmed in the device.

Normal mode

- Depending on the reception quality in the network, the heat cost allocator automatically determines the sending of a short or long telegram. The sending intervals correspond to the values programmed in the device.

Automatic commissioning (by default)

General remarks:

- The welding gap for M3 threaded bolts must be 50 mm. Before welding, the paint on the welding points must be scraped off. Weld the bolts on a surface or groove containing water.
- Use only M3 threaded bolts with a maximum length of 8mm or there is a risk of damaging the heat cost allocator.
- It is not possible to weld on aluminum radiators.
- On radiators with an even number of sections, the heat cost allocator has to be mounted between the center sections.
- On radiators with an odd number of sections, the heat cost allocator has to be mounted between the two sections following the central section in the forward direction.
- Mount the back plate through the 2 oval holes and fit it to the top edge.

For more information about mounting on different types of radiators and fasteners please contact your local Sontex agent.

Mounting of the remote sensor

For each version of heat cost allocator, it is possible to plug the connector of the remote sensor into an interface inside the heat cost allocator. The remote sensor will be automatically detected by the heat cost allocator.

Once equipped with a remote sensor, the heat cost allocator will only work for an application with remote sensor. Remote sensor version with 2 m or 5 m cable. The cable includes a stopper-knot.

In case of combined valve- and flap-controlled radiators, the installation of an electronic heat cost allocator is only permitted if the flap control is dismounted or maintained in position "open".

Convector heaters where the performance can be altered by an electric blower as well as heat towel racks with an electric heating cartridge may only be equipped with an electronic heat cost allocator if the additional electric attachments are dismounted or shut down.

The heat cost allocator is an electronic device which – like all other similar devices – has to be handled with care. It is sensible to be electric discharge and contacting certain areas of the PCB. Electric discharge can destroy the device or – even worse – damage it in a way that it fails after an indefinite period of time. For this reason it is essential in any case to avoid contact with the PCB.

Heat cost allocators may only be installed or replaced by qualified personnel.

Before mounting

- Before installation, check that the unit has not been damaged.
- Don't let it fall
- If the heat cost allocator has fallen off, it must not be reinstalled.

Safety with Lithium batteries

Lithium batteries are used, some safety rules must be observed. In particular, replacement of the batteries is not allowed. When recycling the device, please observe the following points: Do not recharge or short-circuit them, protect them from moisture or strong heat exposure, do not throw them into fire and keep them out of reach of children.

Mounting

Mounting position

The mounting position on the radiator is directly related to the type of radiator, its heat output and the heat cost allocator. To ensure correct data acquisition, the heat cost allocators must be installed and operated in a certain position in accordance with the regulations.

The heat radiation from the radiator is transmitted directly to the temperature sensor or remote sensor of the heat cost allocator via the mounting plate.

Sontex 56x & 8x8

Installationsanleitung

Sontex your link to innovative metering

Lieferumfang

Produktbeschreibung

Commissioning by pressing the push button (specify by ordering)

Transition from sleeping to installation mode is achieved by pushing the push button during 3 seconds:

The ● symbol indicates that the heat cost allocator is in installation mode.

List of the error codes

- Err.1 Manipulation (fraud). Check the fixing of the heat cost allocator on the back plate.*
- Err.2 Measurement error. Check the contact of the remote sensor.*
- Err.32 Push button constantly activated.
- Err.64 Measured temperature not within temperature range (0..105°C; 0..120°C for remote sensor).* If the error persists, please return the heat cost allocator to your Sontex agent.

Setting

The software Prog6 allows the parameterization over the optical interface.

The settings of the Sontex 878 LoRaWAN must be done with the Superprog software.

Communication Indicator

Return the heat cost allocator and plug the connector of the remote sensor into the interface inside the heat cost allocator.

Insert the remote sensor cable into the groove provided up to the slot of housing. Place the stopper-knot inside the housing. The knot will avoid any traction on the connector.

Proceed to the commissioning of the heat cost allocator on the aluminum back plate. Take care not to pinch the cable. Respect the color code of the radiator sensor and the remote sensor:

- Heat cost allocator Sontex 56 X, Sontex 566 X, Sontex 868 X and 878 X: the radiator sensor and the remote sensor are manufactured with a yellow color.
- Heat cost allocator Sontex 565, Sontex 566, Sontex 868 and Sontex 878: the radiator sensor and the remote sensor are manufactured with a white color.

LoRaWAN: When the outgoing arrow appears a JOIN request has been transmitted to the LoRaWAN network, but no response from the network has been received. If the connection could not be established, the JOIN process repeats once a day.

LoRaWAN: Incoming and outgoing arrow visible. The connection with the network is functional.

In the case of divergences, the English version takes precedence.

Technical support

For technical support contact your local Sontex agent or Sontex SA directly.

Declaration of conformity

The detailed declaration of conformity can be found and downloaded on our homepage www.sontex.ch

Hotline Sontex

support@sontex.ch
+41 32 488 30 04

Technical modifications subject to change without notice

Operation mode Radio Sontex (566)

Walk-by Radio Remote Readout

Installation mode

- Radio availability 24h / 24h

Normal mode

- Readout of the data of the heat cost allocator 566 is possible every day from 6.00 to 17.59 (winter time).

Operation mode Radio wM-Bus (868)

Readout over the long telegram for Walk-by reading

Installation mode

- Radio availability 24h / 24h
- Transmission interval each 30 seconds

Normal mode

- Transmission interval each 120 seconds (minimum)
- 24h / 24h, 7 / 7 days

Type of telegram must be defined when ordering.

Operation mode LoRaWAN-class A (878)

Installation mode

- In this mode, the connection procedure (JOIN) is initiated automatically. The JOIN procedure is repeated once a day if the network connection cannot be established. Depending on the reception quality in the network, the heat cost allocator automatically determines the sending of a short or long telegram. The sending intervals correspond to the values programmed in the device.

Normal mode

- Depending on the reception quality in the network, the heat cost allocator automatically determines the sending of a short or long telegram. The sending intervals correspond to the values programmed in the device.

Automatic commissioning (by default)

General remarks:

- The welding gap for M3 threaded bolts must be 50 mm. Before welding, the paint on the welding points must be scraped off. Weld the bolts on a surface or groove containing water.
- Use only M3 threaded bolts with a maximum length of 8mm or there is a risk of damaging the heat cost allocator.
- It is not possible to weld on aluminum radiators.
- On radiators with an even number of sections, the heat cost allocator has to be mounted between the center sections.
- On radiators with an odd number of sections, the heat cost allocator has to be mounted between the two sections following the central section in the forward direction.
- Mount the back plate through the 2 oval holes and fit it to the top edge.

For more information about mounting on different types of radiators and fasteners please contact your local Sontex agent.

Mounting of the remote sensor

For each version of heat cost allocator, it is possible to plug the connector of the remote sensor into an interface inside the heat cost allocator. The remote sensor will be automatically detected by the heat cost allocator.

Once equipped with a remote sensor, the heat cost allocator will only work for an application with remote sensor. Remote sensor version with 2 m or 5 m cable. The cable includes a stopper-knot.

In case of combined valve- and flap-controlled radiators, the installation of an electronic heat cost allocator is only permitted if the flap control is dismounted or maintained in position "open".

Convector heaters where the performance can be altered by an electric blower as well as heat towel racks with an electric heating cartridge may only be equipped with an electronic heat cost allocator if the additional electric attachments are dismounted or shut down.

The heat cost allocator is an electronic device which – like all other similar devices – has to be handled with care. It is sensible to be electric discharge and contacting certain areas of the PCB. Electric discharge can destroy the device or – even worse – damage it in a way that it fails after an indefinite period of time. For this reason it is essential in any case to avoid contact with the PCB.

Heat cost allocators may only be installed or replaced by qualified personnel.

Before mounting

- Before installation, check that the unit has not been damaged.
- Don't let it fall
- If the heat cost allocator has fallen off, it must not be reinstalled.

Safety with Lithium batteries

Lithium batteries are used, some safety rules must be observed. In particular, replacement of the batteries is not allowed. When recycling the device, please observe the following points: Do not recharge or short-circuit them, protect them from moisture or strong heat exposure, do not throw them into fire and keep them out of reach of children.

Mounting

Mounting position

The mounting position on the radiator is directly related to the type of radiator, its heat output and the heat cost allocator. To ensure correct data acquisition, the heat cost allocators must be installed and operated in a certain position in accordance with the regulations.

The heat radiation from the radiator is transmitted directly to the temperature sensor or remote sensor of the heat cost allocator via the mounting plate.

Sontex 56x & 8x8

Installationsanleitung

Sontex your link to innovative metering

Lieferumfang

Produktbeschreibung

Commissioning by pressing the push button (specify by ordering)

Transition from sleeping to installation mode is achieved by pushing the push button during 3 seconds:

The ● symbol indicates that the heat cost allocator is in installation mode.

List of the error codes

- Err.1 Manipulation (fraud). Check the fixing of the heat cost allocator on the back plate.*
- Err.2 Measurement error. Check the contact of the remote sensor.*
- Err.32 Push button constantly activated.
- Err.64 Measured temperature not within temperature range (0..105°C; 0..120°C for remote sensor).* If the error persists, please return the heat cost allocator to your Sontex agent.

Setting

The software Prog6 allows the parameterization over the optical interface.

The settings of the Sontex 878 LoRaWAN must be done with the Superprog software.

Communication Indicator

Return the heat cost allocator and plug the connector of the remote sensor into the interface inside the heat cost allocator.

Insert the remote sensor cable into the groove provided up to the slot of housing. Place the stopper-knot inside the housing. The knot will avoid any traction on the connector.

Proceed to the commissioning of the heat cost allocator on the aluminum back plate. Take care not to pinch the cable. Respect the color code of the radiator sensor and the remote sensor:

- Heat cost allocator Sontex 56 X, Sontex 566 X, Sontex 868 X and 878 X: the radiator sensor and the remote sensor are manufactured with a yellow color.
- Heat cost allocator Sontex 565, Sontex 566, Sontex 868 and Sontex 878: the radiator sensor and the remote sensor are manufactured with a white color.

LoRaWAN: When the outgoing arrow appears a JOIN request has been transmitted to the LoRaWAN network, but no response from the network has been received. If the connection could not be established, the JOIN process repeats once a day.

LoRaWAN: Incoming and outgoing arrow visible. The connection with the network is functional.

In the case of divergences, the English version takes precedence.

Technical support

For technical support contact your local Sontex agent or Sontex SA directly.

Declaration of conformity

The detailed declaration of conformity can be found and downloaded on our homepage www.sontex.ch

Hotline Sontex

support@sontex.ch
+41 32 488 30 04

Technical modifications subject to change without notice

Operation mode Radio Sontex (566)

Walk-by Radio Remote Readout

Installation mode

- Radio availability 24h / 24h

Normal mode

- Readout of the data of the heat cost allocator 566 is possible every day from 6.00 to 17.59 (winter time).

Operation mode Radio wM-Bus (868)

Readout over the long telegram for Walk-by reading

Installation mode

- Radio availability 24h / 24h
- Transmission interval each 30 seconds

Normal mode

- Transmission interval each 120 seconds (minimum)
- 24h / 24h, 7 / 7 days

Type of telegram must be defined when ordering.

Operation mode LoRaWAN-class A (878)

Installation mode

- In this mode, the connection procedure (JOIN) is initiated automatically. The JOIN procedure is repeated once a day if the network connection cannot be established. Depending on the reception quality in the network, the heat cost allocator automatically determines the sending of a short or long telegram. The sending intervals correspond to the values programmed in the device.

Normal mode

- Depending on the reception quality in the network, the heat cost allocator automatically determines the sending of a short or long telegram. The sending intervals correspond to the values programmed in the device.

Automatic commissioning (by default)

General remarks:

- The welding gap for M3 threaded bolts must be 50 mm. Before welding, the paint on the welding points must be scraped off. Weld the bolts on a surface or groove containing water.
- Use only M3 threaded bolts with a maximum length of 8mm or there is a risk of damaging the heat cost allocator.
- It is not possible to weld on aluminum radiators.
- On radiators with an even number of sections, the heat cost allocator has to be mounted between the center sections.
- On radiators with an odd number of sections, the heat cost allocator has to be mounted between the two sections following the central section in the forward direction.
- Mount the back plate through the 2 oval holes and fit it to the top edge.

For more information about mounting on different types of radiators and fasteners please contact your local Sontex agent.

Mounting of the remote sensor

For each version of heat cost allocator, it is possible to plug the connector of the remote sensor into an interface inside the heat cost allocator. The remote sensor will be automatically detected by the heat cost allocator.</



Sontex 56x & 8x8


Guide d'installation



Contenu à la livraison



Description du produit



Instructions d'installation et d'utilisation

Général

Le répartiteur de frais de chauffage est un instrument de mesure de précision agréé pour la répartition de frais de chauffage et doit être manipulé avec soin.

La gamme de répartiteur de frais de chauffage Sontex est conforme aux exigences de la directive européenne EN 854:2013.

Le répartiteur de frais de chauffage doit être utilisé dans le respect des conditions de fonctionnement indiquées. Le scellement doit rester intact. Une utilisation hors de ces conditions exclue toute responsabilité du fabricant, la garantie d'usine et la conformité métrologique ne seront plus assurées.

Les répartiteurs de frais de chauffage ne peuvent pas être installés dans des systèmes de chauffage, dont les radiateurs sont chauffés par de la vapeur, des chauffages au sol, des chauffages irradiant au plafond et pour des radiateurs commandés par clapets, radiateurs électriques.

Pour les radiateurs combinés commandés par clapets et vannes, l'installation de répartiteurs de frais de chauffage est uniquement admise si les clapets sont démontés ou sont maintenus en position „ouverte“.

Les convecteurs qui possèdent un réglage de la puissance ainsi que les corps de chauffe pour des serviettes de bain ne permettent pas l'installation de répartiteurs sauf si un démontage de la partie électrique complémentaire a été effectué.

Les répartiteurs de frais de chauffage Sontex sont des appareils électroniques qui, comme tous les autres appareils comparables, doivent être manipulés avec soin. Ils sont sensibles aux décharges électriques. Elles peuvent détruire l'appareil immédiatement ou l'endommager au point de le rendre inutilisable. Évitez à tout prix de toucher le circuit imprimé.

Les répartiteurs de frais de chauffage ne doivent pas être installés ou remplacés que par du personnel qualifié.

Avant le montage

- Avant l'installation, vérifiez que l'appareil n'a pas été endommagé.
- Ne pas laisser tomber
- Si le répartiteur de frais de chauffage est tombé, il ne doit pas être réinstallé.

Sécurité sur les piles au lithium

Des piles au Lithium sont utilisées, certaines règles de sécurité doivent être respectées. **Normalement, le remplacement des piles ne sont pas autorisés.**


Lors du recyclage de l'appareil, veuillez respecter les points suivants : Ne pas les recharger ou court-circuiter, les protéger de l'humidité ou à une forte exposition de chaleur, ne pas les jeter au feu et les tenir hors de portée des enfants.

Montage


La position de montage sur le radiateur est en rapport direct avec le type de radiateur, sa puissance calorifique et le répartiteur de frais de chauffage. Pour garantir une saisie correcte des données, les répartiteurs de frais de chauffage doivent être montés et exploités à une certaine position dans le respect des prescriptions.

Le rayonnement de chaleur du radiateur est transmis via la plaque de montage directement à la sonde de température ou à la sonde à distance du répartiteur.

- Les répartiteurs Sontex sont à installés selon les descriptions ci-dessous.



En cas de montage mural, la sonde à distance est fixée sur le radiateur et le répartiteur de frais de chauffage est fixé au mur à l'aide du rail en aluminium fourni.



Le montage mural avec sonde à distance doit également être effectué si, en raison de la conception du radiateur, il n'y a pas de contact suffisant avec les éléments conducteurs d'eau.

Un montage mural doit être effectué quand le radiateur est plus petit que 250 mm en hauteur ou si pour des raisons d'esthétique ou d'éclaboussures d'eau, le répartiteur ne peut pas être monté sur le radiateur.

Remarques générales :

- L'écartement pour le soudage des goussets filetés M3 doit être de 50 mm. Avant le soudage, la peinture des points de soudure doit être éliminée. Souder les goussets sur une surface ou une rameuse contenant de l'eau.
- Utilisez toujours des goussets filetés M3 avec une longueur maximale de 8mm ou il y a un risque d'endommager le répartiteur.
- Il n'est pas possible de faire de soudage sur les radiateurs en aluminium.
- Sur les radiateurs à nombre pair de sections, le répartiteur est monté entre les sections centrales.
- Sur les radiateurs à nombre de sections impaires, le répartiteur est installé entre les deux sections suivant la section centrale en direction de l'aller.
- Montez la plaque arrière à travers les 2 trous ovales et ajustez-la sur le bord supérieur.

Pour plus de renseignement concernant le montage sur différents types de radiateurs et les pièces de fixation veuillez contacter l'agent Sontex de votre pays.


Montage de la sonde à distance

Pour chaque modèle de répartiteur, il est possible d'enfoncer le connecteur de la sonde à distance dans une interface à l'intérieur du répartiteur.


La sonde à distance sera automatiquement reconnue par le répartiteur lors du montage.

Une fois équipée d'une sonde à distance, le répartiteur de frais de chauffage ne pourra fonctionner que pour une application avec sonde à distance.

La longueur du câble de la sonde à distance est de 2 ou 5 mètres. Le câble comporte un nœud d'arrêt.



Le paramétrage du Sontex 878 LoRaWAN doit se faire avec le logiciel Superprog.



Dès que le répartiteur sera fixé sur le rail en aluminium, l'affichage du répartiteur indiquera le message suivant :

L'index FF indique que le répartiteur a reconnu la sonde à distance.

L'index -- indique que le répartiteur fonctionne avec une sonde radiateur compact ou qu'il n'a pas reconnu la sonde à distance.

Cette information sera affichée pendant 5 secondes, après quoi le répartiteur changera automatiquement de mode.

Pousser le plomb préinstallé par Sontex dans l'ouverture du boîtier. Presser jusqu'à l'arrêt sur le rail en aluminium.

Le choix du télégramme court ou long se fait lors de la commande.

Disponibilité Radio LoRaWAN-classe A (878)

En mode d'installation:

- La radio est disponible 24h / 24h avec un intervalle d'émission toutes les 30 secondes.

En mode normal:

- Intervalle d'émission toutes les 120 secondes (standard).

■ Période d'envoi, 12h au choix par jour (programmable), 5 / 7 jours.

■ La radio est disponible 24h / 24h avec un intervalle d'émission toutes les 30 secondes.

En mode d'installation:

- La radio est disponible 24h / 24h avec un intervalle d'émission toutes les 30 secondes.

En mode normal:

- Intervalle d'émission toutes les 120 secondes (standard).

■ Période d'envoi, 24h / 24h, 7 / 7 jours.

Le choix du télégramme court ou long se fait lors de la commande.

Disponibilité Radio LoRaWAN-classe A (878)

En mode d'installation:

- Dans ce mode, la procédure de connexion (JOIN) est lancée automatiquement. La procédure JOIN est répétée une fois par jour si la connexion au réseau ne peut pas être établie.

En fonction de la qualité de la réception dans le réseau, le répartiteur de frais de chauffage détermine automatiquement l'envoi d'un télégramme court ou long. Les intervalles d'envoi correspondent alors aux valeurs programmées dans l'appareil.

En mode normal:

- En fonction de la qualité de la réception dans le réseau, le répartiteur de frais de chauffage détermine automatiquement l'envoi d'un télégramme court ou long. Les intervalles d'envoi correspondent alors aux valeurs programmées dans l'appareil.

En mode d'installation:

- Dans ce mode, la procédure de connexion (JOIN) est lancée automatiquement. La procédure JOIN est répétée une fois par jour si la connexion au réseau ne peut pas être établie.

En fonction de la qualité de la réception dans le réseau, le répartiteur de frais de chauffage détermine automatiquement l'envoi d'un télégramme court ou long. Les intervalles d'envoi correspondent alors aux valeurs programmées dans l'appareil.

Il montaggio a parete è necessario se il radiatore ha un'altezza inferiore a 250 mm o se il ripartitore non può essere montato sul radiatore per motivi estetici e/o impossibilità tecnica.

Il montaggio a parete con sensore remoto deve essere effettuato anche se, a causa della struttura del radiatore, non c'è un contatto sufficiente con gli elementi portanti dell'acqua.

En modo normal:

- En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

Il montaggio a parete è necessario se il radiatore ha un'altezza inferiore a 250 mm o se il ripartitore non può essere montato sul radiatore per motivi estetici e/o impossibilità tecnica.

Il montaggio a parete con sensore remoto deve essere effettuato anche se, a causa della struttura del radiatore, non c'è un contatto sufficiente con gli elementi portanti dell'acqua.

En modo normal:

- En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

Il montaggio a parete è necessario se il radiatore ha un'altezza inferiore a 250 mm o se il ripartitore non può essere montato sul radiatore per motivi estetici e/o impossibilità tecnica.

Il montaggio a parete con sensore remoto deve essere effettuato anche se, a causa della struttura del radiatore, non c'è un contatto sufficiente con gli elementi portanti dell'acqua.

En modo normal:

- En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

Il montaggio a parete è necessario se il radiatore ha un'altezza inferiore a 250 mm o se il ripartitore non può essere montato sul radiatore per motivi estetici e/o impossibilità tecnica.

Il montaggio a parete con sensore remoto deve essere effettuato anche se, a causa della struttura del radiatore, non c'è un contatto sufficiente con gli elementi portanti dell'acqua.

En modo normal:

- En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

Il montaggio a parete è necessario se il radiatore ha un'altezza inferiore a 250 mm o se il ripartitore non può essere montato sul radiatore per motivi estetici e/o impossibilità tecnica.

Il montaggio a parete con sensore remoto deve essere effettuato anche se, a causa della struttura del radiatore, non c'è un contatto sufficiente con gli elementi portanti dell'acqua.

En modo normal:

- En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

Il montaggio a parete è necessario se il radiatore ha un'altezza inferiore a 250 mm o se il ripartitore non può essere montato sul radiatore per motivi estetici e/o impossibilità tecnica.

Il montaggio a parete con sensore remoto deve essere effettuato anche se, a causa della struttura del radiatore, non c'è un contatto sufficiente con gli elementi portanti dell'acqua.

En modo normal:

- En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

Il montaggio a parete è necessario se il radiatore ha un'altezza inferiore a 250 mm o se il ripartitore non può essere montato sul radiatore per motivi estetici e/o impossibilità tecnica.

Il montaggio a parete con sensore remoto deve essere effettuato anche se, a causa della struttura del radiatore, non c'è un contatto sufficiente con gli elementi portanti dell'acqua.

En modo normal:

- En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

Il montaggio a parete è necessario se il radiatore ha un'altezza inferiore a 250 mm o se il ripartitore non può essere montato sul radiatore per motivi estetici e/o impossibilità tecnica.

Il montaggio a parete con sensore remoto deve essere effettuato anche se, a causa della struttura del radiatore, non c'è un contatto sufficiente con gli elementi portanti dell'acqua.

En modo normal:

- En función de la calidad de la recepción en el rededor, el repartidor de calor determina automáticamente la envío de un telegrama corto o largo. Los intervalos de envío corresponden a los valores programados en el dispositivo.

En función de la calidad de la recepción en el rededor, el repartidor de