

KONA Micro Gateway

Schnellstartanleitung

Einschalten des Gateways

Dieses KONA Micro Gateway unterstützt eine externe LoRa-Antenne, Kupfer-Ethernet-Backhaul und optional 3G/4G-Wireless-Backhaul. Alle Gateway-Modelle werden über ein AC-DC-Netzteil mit Strom versorgt und können optional mit einer internen Backup-Batterie ausgestattet werden.



Hinweis:

Weitere Anweisungen zum Zusammenbau des Zubehörs finden Sie im Einrichtungsvideo:

https://www.youtube.com/watch?v=_V3e2nn2wl

Konfiguration und Aktivierung

Nehmen Sie das Gateway mit der LeapX-Anwendung in Betrieb

Um LeapX nutzen zu können, benötigen Sie ein TEKTELIC-Konto. Wenn Sie noch kein Konto haben, erstellen Sie bitte ein Ticket in unserem Support-Portal support.tektelic.com. Unser Support-Team wird dann ein Konto für Sie erstellen.

Um die LeapX-Anwendung auf Ihrem Smart-Gerät zu installieren, suchen Sie bitte im Google Play Store oder im Apple App Store nach „TEKTELIC LeapX“. Sobald die App installiert ist, melden Sie sich mit dem Benutzernamen und Passwort Ihres TEKTELIC-Kontos bei der App an. Befolgen Sie dann die Anweisungen in der App online.



Hinweis:

Sobald das Gateway „Online“ anzeigt, können Sie Sensoren zu Ihrem Netzwerk hinzufügen.

Fehlerbehebung beim Gateway

KONA Micro LED-Zustände

LED State	Functional Description	How long is it reasonable to stay in this State?
No LED	No power to gateway	Until power is applied
Solid Green	Gateway is operational with a packet forwarder running. LoRaWAN packet transmission and reception functions are operating normally.	It should stable in this state.
Flashing Green	Module is Initializing or No downlink packets have been transmitted by the gateway in the last 10 minutes.	Up to 15 minutes – Includes time for software upgrade or recovery. Typical boot time is < 2 minutes. or Until the gateway starts transmitting packets. (downlink packets)
Solid Red	Unit is in fault condition and requires service	Undesired stable state. Power cycle the gateway. If the condition persists, contact customer support.

Hinweis:

Wenn Sie Fragen zu diesem Gateway haben, besuchen Sie das TEKTELIC Support-Portal unter support.tektelic.com, um auf unsere Wissensdatenbank zuzugreifen.