LW001-BG Datasheet EN V1.3

Version	Description	Editor	Date
1.0	initial version create	xrs	2019-05-23
1.1	1.change battery level from percentage to normal or low battery indicate in upload data 2.cancel the low battery indicate light	xrs	2019-07-22
1.2	add appendix table	xrs	2019-10-07
1.3	firmware update to V1.1.3: fix the bug of automatic reboot and update the format of the second packet	xrs	2019-10-15

- 1 Product Introduction
- 2 Application
- 3 Product Feature
- 4 Technical Parameter
  - 4.1 Wireless Parameter
  - 4.2 Hardware Specification
  - 4.3 Operating Environment
  - 4.4 Product Appearance
    - 6.4.1 Product Interface
    - 6.4.2 Product Dimension
- 5 Operation Instruction
  - 5.1 Quick access network guide
  - 5.2 Uplink Payload Instruction
    - 5.2.1 First data packet
    - 5.2.2 Second data packet
  - 5.3 Configuration parameter changes and firmware upgrades
- 6. Troubleshooting
  - 6.1 The device can't connect to the LoRaWAN network
  - 6.2 APP can't connect to the device
- 7 Order Information
- 8 Appendix Table
  - 8.1 Default Uplink Channels

1 Product Introduction

LW001-BG is a wireless smart asset ultra-low power consumption LoRaWAN GPS Tracker. Which is based on standard LoRaWAN protocol that is suitable for long distance transmission,built-in GPS & Bluetooth & Acc-motion tracking sensor. It support ABP and OTAA two different network access mode, and easy to configure and update firmware by Mokolora APP.

Ideal to optimize logistic process,asset management, warehouse and inventory management, vehicle tracking, theft protection and much more. In a definable interval, LW001-BG automatically reports its longitude,latitude,speed,battery level and so on.Mine also could provide customized service to suit your application scenarios.

2 Application

- Perfect for professional asset management tracking and location
- Smart animal farming
- Logistics and supply chain management
- Smart cities
- Smart home and objects
- Smart factory

3 Product Feature

- Based on LoRaWAN™ Protocol
- Built-in GPS module for fast accuracy within 2.5m CEP
- Built-in 6-Axis motion tracking sensor, support moving object detection
- Support for configuring ABP and OTAA modes with MokoLora APP
- Support for updating APP via BLE
- Support a wide range frequency:CN470-510MHZ EU868MHZ AU915MHZ US915MHZ AS923MHZ
- 4000mAh non-chargeable battery
- Ultra Low Power, 7days 5-over operating time (Data are reported twice a day)
- Low battery indicator

4 Technical Parameter

4.1 Wireless Parameter

Item	Parameters
Protocol	LoRaWAN
LoRa Data Rate	250bps~5.46bps
LoRa Frequency	CN470/EU868/AU915/US915/AS923/IN865/KR920/RU/AS3/CN470/CN779
Max Transmitter Power	19dBm
Sensitivity	-142.5dBm@SF12 300bps

4.2 Hardware Specification

Item	Parameters
MCU	NRF52832-QFAA
Memory	Flash 512KB,RAM 64KB
Power Supply	4000mAh non-chargeable battery
Operating time	max.5 years @upload data twice per day
Sleep Mode Current	<=20uA
Operating Current	Max 150mA@18dBm
LoRa Communication Distance	>=500m in wide-open area
Positioning Mode	GPS, accuracy 2.5m CEP
Motion Tracking	built in 3-axis accelerometer MPU-9250

4.3 Operating Environment

Item	Parameters
Operating Temperature	-40~+70℃
Operating Humidity	10%~90%

Product Specification

Item	Parameters
Dimension	108.6 x 65 x 33.2mm
IP Rating	IP65

4.4 Product Appearance

4.4.1 Product Interface

turn on: Press the on/off button and hold 5s. Red LED blink one time then green LED light on three second.It indicate power on successed.

turn off: Press the on/off button and hold 5s. Green LED blink three second. It indicate power off successed.

4.4.1 Product Dimension



5. Operation Instruction

LW001-BG has been pre-installed with firmware. The default configuration mode of the device is LoRaWAN OTAA and the device type is Class A. Under the default configuration, user can use the OTAA key that we provide with product add the device to the LoRaWAN server, the device will automatically connect to the network after the device turn on.

Please use MokoLora APP when the user needs to change the OTAA key and other configuration parameters. The user can also use MokoLora APP to add the device to the server.Information please read the MokoLora APP user manual.

5.1 Quick access network guide

We will based on an 8-channel LoRaWAN gateway and web-base LoRaWAN server to introduce the access network process in below passage.

Before entering the network, the LoRaWAN gateway needs connect to the internet and configured with the LoRaWAN server. And please makesure gateway frequency same with the device frequency. Here is the simple LoRaWAN network structure.

Step 1: Add device to LoRaWAN server

The default access network mode of the device is OTAA. Add the OTAA device to the server. Fill in the information according to the OTAA key (DevEUI, AppEUI, AppKey) provided by our company or read the device data by APP.

```
**Device name:** Default device name LW001_BG_xxxx, which can be changed by a the user.
**DevEUI:** Please refer to the information provided by our company. Each device have a different DevEUI and it is unique to the server.
**AppEUI:** **Default is 5A5058544C5748**
**AppKey:** **Default is 2C7CFA22BA4D4AAE7710DB7FC497A7C**
**Frequency band:** **Select the Frequency Table we with the device.**
**Device type:** ** default Class A
```

Step 2: Press the on/off button and hold 5s

Red LED blink one time then green LED light on three second.It indicate power on successed.

Step 3: The device will automatically connect to LoRaWAN server after the device turn on. When device connect to LoRaWAN server successed, it will start uploading data to the server. The default data upload interval on the device is 10 minutes.

5.2 Uplink Payload Instruction

Each complete uplink payload data consists of two hexadecimal data packets, and the length of each data packet is 10 bytes.

Function description: the first data packet contains data total packet number, current packet, latitude and longitude. The second data packet contains the current packet, current battery level, speed, X-axis direction, and Y-axis direction.

5.2.1 First data packet

Type	Byte	Value	Description
total packets	01	0x02	the total packets of uplink data, all the complete data packet are 2
current packet	02	0x01	the number of current packet
latitude	03~06	0x00000000~0xFFFFFFFF	Latitude is represented by the 4-byte float of the IEEE 754 standard, and the byte order is low byte first. The format is converted to decimal data: keep four decimal places, Convert to decimal data:keep four decimal places, Convert to latitude DU: otherwise, it means southern latitude DU
longitude	07~10	0x00000000~0xFFFFFFFF	Longitude is represented by the 4-byte float of the IEEE 754 standard, and the byte order is low byte first. The format is: Add0x.otherwise,when the float converted to decimal data keep four decimal places, converted to decimal positive, to represent the east longitude DU, converted to meana western longitude DU

```
example: 02 01 5E 76 BE 45 F4 29 32 4E
```

Byte	01	02	03-06	07-10
example data	02	01	5E 76 BE 45	F4 29 32 4E
example description	the total data packet is 2	this is the first data packet	convert to decimal data and keep 4 decimal place is 1123.5070, Latitude DU degree 39 minutes and 0.5070 second	convert to decimal data and keep 4 decimal place is 1402.4850, Longitude DU degree 50 minutes and 0.4850 second

5.2.2 Second data packet

Type	Byte	Value	Description
total packets	01	0x02	the total packets of uplink data, all the complete data packet are 2
current packet	02	0x02	the number of current packet
battery level	03	0x00, 0X01	the current battery level,00 indicate normal battery,01 indicate low battery
speed	04~07	0x00000000~0xFFFFFFFF	speed is represented by the 4-byte float of the IEEE 754 standard, and the byte order is low byte first. when the float converted to decimal data keep four decimal places
X-axis	08~09	0x0000~0xFFFF	X-axis direction of 0 axis sensor , byte order is low byte first,when converted to decimal data need divide by 10
Y-axis	10~11	0x0000~0xFFFF	Y-axis direction of 0 axis sensor , byte order is low byte first,When convert to decimal data need divide by 100

```
example: 02 02 00 FA 19 DE 3E 42 01 01
```

Byte	01	02	03	04-07	08-09
example data	02	02	00	FA 19 DE 3E	1C 46
example description	This is the data packet	This is the data packet	current battery level is normal	convert to decimal data and keep 4 decimal places is 0.1737, means speed 0.1737 meters, convert to km/h 0.1737*3.6=0.6253km/h	convert to integ ral(1796), it means the X-axis of 0 axis sensor is 1796/10=179.6 degree

5.3 Configuration parameter changes and firmware upgrades

If user need change the device settings or upgrade firmware,this can be done through the MokoLora APP. The detail operations can refer to below APP user manual.

http://doc.mokotechnology.com/index.php?s=/18&page_id=32

After changed the device settings needs add the device in the server, and please fill in the device information as modified. Detail operation please refer to 5.1.

If user change the LoRaWAN mode to ABP, then need add ABP device in server, and other information should keep the same as in APP.

6. Troubleshooting

6.1 The device can't connect to the LoRaWAN network

- Please check the if the device turn on successed.
- Please check if the frequency of the LoRaWAN gateway is same as device.

6.2 APP can't connect to the device

- Please check if the device turn on successed.
- Please check if the system software of the phone meet requirements. Android system requires above version 4.4, IOS system need above version 9.0.
- Please check if your phone bluetooth is open.

For more issues please contact our network staff.

7 Order Information

Product code	Frequency
LW001-BG-EU868	EU868
LW001-BG-US915	US915
LW001-BG-AU915	AU915
LW001-BG-IN865	IN865
LW001-BG-KR920	KR920
LW001-BG-AS923	AS923
LW001-BG-EU433	EU433
LW001-BG-CN470	CN470
LW001-BG-CN779	CN779

8 Appendix Table

8.1 Default Uplink Channels

Band/Ch	0	1	2	3-48	Define Data Rate
EU868	868.1 DR0-DR5	868.3 DR0-DR5	868.5 DR0-DR5	-	0
US915	902.3 DR0-DR3	902.5 DR0-DR3	902.7 DR0-DR3	0~63 : 903.0 + ch x 0.2 DR0-DR3 64~71 : 903.0 + ch-64x 1.6 DR4	0
US915-HYBRID	902.3 DR0-DR3	902.5 DR0-DR3	902.7 DR0-DR3	0~7 902.3 + ch x 0.2 DR0-DR3 64 903.0 + ch-64x 1.6 DR4	0
CN779	779.5 DR0-DR5	779.7 DR0-DR5	779.9 DR0-DR5	-	0
EU433	433.175 DR0-DR5	433.375 DR0-DR5	433.575 DR0-DR5	-	0
AU915	915.2 DR0-DR3	915.4 DR0-DR3	915.6 DR0-DR3	0~63 915.2 + ch x 0.2 DR0-DR3 64~71 915.3 + ch-64 x 1.6 DR4	0
AU915OLD	915.2 DR0-DR3	915.4 DR0-DR3	915.6 DR0-DR3	0~63 915.2 + ch x 0.2 DR0-DR3 64~71 915.3 + ch-64 x 1.6 DR4	0
CN470	470.3 DR0-DR5	470.5 DR0-DR5	470.7 DR0-DR5	200KHz channel space up to 96	0
AS923	923.2 DR0-DR5	923.4 DR0-DR5	-	-	2
KR920	922.1 DR0-DR5	922.3 DR0-DR5	922.5 DR0-DR5	-	0
IN865	865.0625 DR0-DR5	865.4025 DR0-DR5	865.985 DR0-DR5	-	0
CN470PREQUEL	471.3 DR0-DR5	471.7 DR0-DR5	471.9 DR0-DR5	200KHz channel space up to 7	0
STE920	922.0 DR0-DR5	922.2 DR0-DR5	922.4 DR0-DR5	200KHz channel space up to 7	0

Notice:

1、LW001-BG support all of the uplink channels of different band in the table, But be sure default settings of the su channel in the table are the same as the gateway channel, for example, the default channel of the US band for private user through APP, according your actual channel band.

Examples: US915 support max 72 channels, so channels numbered 0 to 63 utilizing 125k CCI bw 64 starting from 902.3 in steps of 200kHz, and 64 to 71 utilizing 500k CCI bw with a starting at 903.0, and also incrementing linearly by 1.6MHz as follows:

0 channels numbered 0 to 7 utilizing 125k CCI bw 64 to 71 utilizing 500k CCI bw

2、The band range **can first to the table** below belong to **LoRaWAN** standard channel plan can be customized.