### **M**ilesight



## Milesight





Cloud App

Quick Start Guide

# **Box**IAQ Kit

**Indoor Air Quality Monitoring** 

### **QUICK START GUIDE**

All software & files can be downloaded from https://www.milesight-iot.com/documents-download/

Better Inside, More in Sight

Milesight IoT Co., Ltd. | www.milesight-iot.com





#### Table of Contents

| 1.Device List                 | 2 |
|-------------------------------|---|
| 2.Packing List                | 4 |
| 3.Registration and Activation | 4 |
| 4.Setting-up the Gateway      | 5 |
| 5 Setting-up the Sensors      | 7 |



#### 1. Device List

#### Option A:

| Quantity | Item                          | Description   | Applications   |  |
|----------|-------------------------------|---|--|--|
| 1        | AM103L<br>IAQ Sensor          | AM103L is a 3-in-1 ambience monitoring sensor including the measurement of temperature, humidity and CO2-concentration and can transmit to network server using LoRaWAN* technology.  | Monitor temperature, humidity<br>and COs levels     Indicate COs levels via traffic light     Suitable for office or school indoor<br>air quality monitoring   |  |
| 1        | AM103<br>IAQ Sensor           | AM103 is a 3-in-1 ambience monitoring sensor including the measurement of temperature, humidity and CO- concentration and can display indoor status visually on the E-ink screen in real-time and transmit to network server using LoRaWAN® technology.   | Monitor temperature, humidity<br>and CO <sub>2</sub> levels Indicate CO <sub>3</sub> levels via traffic light<br>and emoticon on the Eink screen Suitable for office or school<br>indoor air quality monitoring  |  |
| 1        | AM307<br>IAQ Sensor           | AM307 is a 7-in-1 ambience monitoring sensor including the measurement of temperature, humidity, COs concentration, TVOC, pressure, light, motion, etc. It can show visually with different modes on the E-ink screen in real-time and transmit to network server using LoRaWAN <sup>a</sup> technology.              | Monitor main pollutants in indoor<br>environment     Indicate polluted levels via traffic<br>light and emotion on the screen     Suitable for office or school indoor<br>ambience monitoring     Real-time alarm with buzzer<br>for polluted indoor air quality  |  |
| 1        | AM319<br>IAQ Sensor           | AM319 is a 9-in-1 ambience monitoring sensor including the measurement of temperature, humidity, COs. concentration, TVOC, pressure, light, motion, PM2-5.8 PM10, LHCHO/Os, et C. to an show visually with different modes on the E-lik screen in real-time and transmit to network server using LoRaWAN* technology. | Monitor main pollutants in indoor<br>environment     Indicate polluted levels via traffic<br>light and emoticon on the screen     Suitable for office or school indoor<br>ambience monitoring     Real-time alarm with buzzer<br>for polluted indoor air quality |  |
| 1        | UG63 Mini<br>LoRaWAN® Gateway | UG63 Mini LoRaWAN* Gateway provides stable connectivity between sensors and mainstream network servers or Milesight IoT Cloud.  | Collect data from LoRaWAN® sensors     Forward data to Milesight toT Cloud or mainstream network servers via Ethernet  |  |

| Quantity | Item                                 | Description   | Applications   |
|----------|--------------------------------------|---|--|
|          | 1 Year (Pro1)<br>Milesight IoT Cloud | Milesight IoT Cloud provides unparalleled<br>levels of vertical integration with Milesight<br>LoRaWANP agleways and sensors. It<br>visualizes field data and enables user to<br>monitor and control remote assets on an<br>intuitive dashboard. | Drag & drop dashboard to<br>display data     Real-time alarm notifications     Exportable historical data and<br>generate reports     Oustom trigger conditions &<br>actions to enable collaborative<br>interaction among end-devices     Android & iOS versions available |

#### Option B:

| Quantity | Item                                 | Description   | Applications   |  |
|----------|--------------------------------------|---|--|--|
| 2        | AM103<br>IAQ Sensor                  | AM103 is a 3-in-1 ambience monitoring sensor including the measurement of temperature, humidity and CO <sub>2</sub> concentration and can display indoor status visually on the E-ink screen in real-time and transmit to network sever   | Monitor temperature, humidity<br>and CO <sub>2</sub> levels Indicate CO <sub>2</sub> levels via traffic light<br>and emoticon on the E-ink screen Suitable for office or school indoor<br>air quality monitoring |  |
| 2        | AM307<br>IAQ Sensor                  | AM307 is a 7-in-1 ambience monitoring sensor including the measurement of temperature, hunding, OCo concentration, TVOC, pressure, light, motion, etc. It can show visually with different modes on the E-ink screen in real-time and transmit to network server using LoRaWAN® technology. | Monitor main pollutants in indoor<br>environment     Indicate polluted levels via traffic<br>light or emoticon on the screen     Suitable for office or school<br>indoor ambience monitoring                     |  |
| 1        | UG63 Mini<br>LoRaWAN® Gateway        | UG63 Mini LoRaWAN® Gateway provides stable connectivity between sensors and mainstream network servers or Milesight IoT Cloud.  | Collect data from LoRaWAN® sensors     Forward data to Milesight IoT Cloud or mainstream network servers via Ethernet  |  |
|          | 1 Year (Pro1)<br>Milesight IoT Cloud |   |  |  |

www.milesight-iot.com www.milesight-iot.com



#### 2. Packing List

| Item                                   | AM103/AM103L | AM307 | AM319 | UG63 |
|--|--------------|-------|-------|------|
| Device                                 | •            | •     | •     | •    |
| Ethernet Cable                         |              |       |       | •    |
| ER14505 Li-SoCl <sub>2</sub> Batteries | •            | •     |       |      |
| Mounting Bracket                       |              | •     | •     |      |
| 3M Double-Sided Tape                   | •            | •     | •     |      |
| Wall Mounting Kits                     | •            | •     | •     | •    |
| Theft-Deterring Screw                  | •            | •     | •     |      |
| Type-C Cable & Power<br>Adapter        |              |       | •     | 0    |
| Warranty Card                          |              | (     | •     |      |

Note: ● =standard, ○=optional.

#### 3. Registration and Activation /

1. Open web browser, navigate to *cloud.milesight-iot.com* to register a Milesight IoT Cloud account. You can also install Milesight IoT Cloud App from Google Play or App store.



2. Activate the account to pro 1 plan by entering the activation code on the web GUI. You can contact your sales representative to get the activation code.



#### 4. Setting-up the Gateway

1. Power on the UG63 via PoE or type-C port.



I OL SWILL

2. Connect the UG63 gateway to PC via Ethernet port or PoE switch and configure the IP address of computer to the same subnet with the UG63 gateway manually (e.g. 192.168.23.200).






3. Type 192.168.23.150 into the browser on PC to log in the web GUI of UG63 gateway.

Username: admin
Password: password

4. Enable the network server and Milesight IoT Cloud mode.



 Select the Connection Type of Ethernet port and fill in the IP information, then connect UG63 gateway Ethernet port to network devices like a router or a modem to get Internet access.





6. Fill in the device SN to add gateway and ensure the gateway is online. You can also enter the SN manually on the Cloud App to add the gateway.




#### 5. Setting-up the Sensors /

1. Install the batteries onto AM103/AM103L devices and AM307 devices.

www.milesight-iot.com www.milesight-iot.com






AM103/AM103L

AM307

For AM319, connect the type-C cable to the USB port and left or right side should make an opening to pass through the type-C cable.



2. Use an NFC-enabled smart phone to install Milesight ToolBox App from Google Play or App store, place the NFC area of phone close to devices and use Milesight ToolBox App to power on, read and configure the device.



For AM307/AM319, you can also connect the type-C port to PC and use ToolBox software downloaded from Milesight website to configure the device.

#### Milesight ToolBox PC:

https://www.milesight-iot.com/software-download/

#### Milesight ToolBox App:





Android


3. Fill in the device SN to add sensors on Milesight IoT Cloud page. You can also use Cloud App to scan the QR code on the label of device to add, or fill in the device SN manually to add sensors.




After devices are getting online, you can view the data on the cloud.

www.milesight-iot.com www.milesight-iot.com 4. Fix devices to the wall via wall mounting kits or 3M tapes, then fix the bottom of the device to the bracket or rear cover with the theft-deterring screw.

#### AM307/AM319:



Fixed by 3M Tapes




Fixed by Screws




Theft-Deterring Screw Installation

#### AM103/AM103L:



Fixed by 3M Tapes



Fixed by Screws



Theft-Deterring Screw Installation

www.milesight-iot.com www.milesight-iot.com 11

## **IAQ Solution**

## Thank you for choosing Milesight Product

Milesight IoT Co., Ltd.